



Seltmann
Weiden

HOTEL

HIGH LIGHTS



MADE IN GERMANY

We produce in Germany



INDEX

4-5	GOOD MOOD white »Mármaros«	40-41	MERAN Fine Dining
6-7	MAXIM Basic	42-43	SALZBURG
8-9	MAXIM Organic	44-45	MARIENBAD
10-11	MAXIM Coup Fine Dining	46-51	COUP FINE DINING »Fashion«
12-13	DIAMANT	52-53	COUP FINE DINING »Karma«
14-15	COUP FINE DINING	54-57	COUP FINE DINING BUFFET GOURMET »Fantastic«
16-17	SAVOY	58-61	COUP FINE DINING »Country Life«
18-19	SAVOY square / rectangular	62-63	COUP FINE DINING »Reflections« »Growth«
20-21	SAVOY »Grand Blue«	64-65	COUP FINE DINING »Blue Sea«
22-25	MANDARIN incl. Event	66-67	MERAN »Springcolors«
26-27	COFFE-E-MOTION	68-69	VIP.COLLECTION
28-29	LAGUNA	70-71	BUFFET PLUS
30-31	LUXOR Fine cream	72-75	BUFFET GOURMET
32-35	MERAN Basic	76-77	MUG TO GO
36-37	MERAN Steak & more	78-79	COMMUNITY
38-39	MERAN Organic	80-81	VITALIS / IMPERIAL



GOOD MOOD

WHITE | »MÁRMAROS«

ITEM DESCRIPTION	PU ¹	Item-No
Coffee pot 1 0,38 ltr. / 13.3 oz.	2	001.751099 ² 001.751229 ³
Sugar Bowl 0,18 ltr. / 6.3 oz.	1	001.751108 ² 001.751232 ³
Creamer 0,14 ltr. / 4.7 oz.	1	001.751102 ² 001.751235 ³
Mocha cup 0,09 ltr. / 3.3 oz.	6	001.751103 ² 001.751236 ³
Saucer M5402-13 13 cm / 5.2 inch	6	001.751099 ² 001.751231 ³
Coffee cup 0,18 ltr. / 6.3 oz.	6	001.751104 ² 001.751237 ³
Cappuccino 0,25 ltr. / cup 8.7 oz.	6	001.751107 ² 001.751240 ³
Mug with handle 0,28 ltr. / 9.7 oz.	6	001.751106 ² 001.751239 ³
Combi saucer M5402-16 16 cm / 6.3 inch	6	001.751105 ² 001.751238 ³
Plate flat M5397-30 30 cm / 11.9 inch	2	001.751089 ² 001.751219 ³
Plate flat M5397-28 28 cm / 11.1 inch	2	001.751088 ² 001.751218 ³
Plate flat M5397-26 26 cm / 10.2 inch	6	001.751087 ² 001.751217 ³
Plate flat M5397-21 21 cm / 8.2 inch	6	001.751430 ² 001.751443 ³
Plate flat M5397-16 16 cm / 6.3 inch	6	001.751080 ² 001.751216 ³
Plate flat oval M5398-29 29 x 21 cm / 11.6 x 8.3 inch	2	001.751093 ² 001.751225 ³
Plate flat oval M5398-32 32 x 23 cm / 12.7 x 9.0 inch	2	001.751094 ² 001.751226 ³
Plate flat oval M5398-36 36 x 26 cm / 14.4 x 10.2 inch	2	001.751095 ² 001.751227 ³

ITEM DESCRIPTION	PU ¹	Item-No
Bowl semi-high M5399-12 12 cm / 4.8 inch	2	001.751424 ² 001.751437 ³
Bowl semi-high M5399-16 16 cm / 6.3 inch	2	001.751090 ² 001.751220 ³
Bowl semi-high M5399-21 21 cm / 8.2 inch	1	001.751091 ² 001.751221 ³
Bowl semi-high M5399-26 26 cm / 10.3 inch	1	001.751092 ² 001.751222 ³
Bowl high M5400-16 16 cm / 6.4 inch	1	001.751425 ² 001.751438 ³
Bowl high M5400-21 21 cm / 8.4 inch	1	001.751426 ² 001.751439 ³
Plate deep coup M5404-16 16 cm / 6.3 inch	4	001.751428 ² 001.751441 ³
Plate deep coup M5404-21 21 cm / 8.3 inch	2	001.751427 ² 001.751440 ³
Plate deep coup M5404-26 26 cm / 10.3 inch	2	001.751429 ² 001.751442 ³
Bowl high 8 cm / 3.1 inch	6	001.751100 ² 001.751223 ³
Bowl low M5403 8 cm / 3.1 inch	6	001.751101 ² 001.751224 ³

²white uni

³»Mármaros« 57570

¹ PU = Packing Unit



ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,38 ltr. / 12.7 oz.	2	001.724967
Tea pot 1 0,55 ltr. / 18.3 oz.	2	001.724970
Warming plate small	1	001.724994
Tea strainer (ACCESSOIRE)	2	001.750850
Rest for tea strainer / Sugar bag container	6	001.726871
Sugar bowl 2 0,28 ltr. / 9.3 oz.	1	001.724974
Sugar dish 8 cm / 3.2 inch	12	001.724973
Creamer 00 0,03 ltr. / 1.0 oz.	12	001.724977
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.724978
Creamer 2 0,25 ltr. / 8.3 oz.	1	001.724979
Mocha cup 0,09 ltr. / 3.0 oz.	6	001.724984
Saucer 13,5 cm / 5.4 inch	6	001.724983
Coffee cup 1 0,16 ltr. / 6.0 oz.	6	001.724985
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Coffee cup 2 0,16 ltr. / 5.3 oz.	6	001.724986
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Milkcoffee cup 0,25 ltr. / 8.3 oz.	6	001.724987
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Breakfast cup 0,32 ltr. / 10.7 oz.	6	001.724988
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Mug with handle 0,28 ltr. / 9.3 oz.	6	001.724992
Mocha cup non stackable 0,09 ltr. / 3.0 oz.	6	001.724982
Saucer 13,5 cm / 5.4 inch	6	001.724983
Coffee cup non stackable 0,16 ltr. / 6.0 oz.	6	001.724989
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Chocolate cup non stackable 0,22 ltr. / 7.3 oz.	6	001.724990
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Milkcoffee cup non stackable 0,37 ltr. / 12.3 oz.	6	001.724990
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Mug with handle non stackable 0,28 ltr. / 9.3 oz.	6	001.724993
Tea cup 0,21 ltr. / 7.0 oz.	6	001.724981
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Cup 0,42 ltr. / 14.0 oz.	6	001.732567
Saucer 1 16,5 cm / 6.7 inch	6	001.724991

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat 33 cm / 13.1 inch	6	001.724938
Plate flat 30 cm / 11.9 inch	6	001.724937
Plate flat 28 cm / 11.2 inch	6	001.724936
Plate flat 26 cm / 10.3 inch	6	001.724935
Plate flat 23 cm / 9.1 inch	6	001.724934
Plate flat 21,5 cm / 8.5 inch	6	001.724933
Plate flat 17 cm / 6.7 inch	6	001.724932
Plate deep 23 cm / 9.1 inch	6	001.724939
Salad plate 19 cm / 7.5 inch	6	001.724949
Pasta plate deep 30 cm / 12.0 inch	2	001.724950
Pasta plate deep 27 cm / 10.8 inch	2	001.724951
Soup cup 0,27 ltr. / 10.0 oz.	6	001.724940
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Eventbowl oval 5257 18 cm / 7.1 x 4.9 inch	2	001.724941
Gravy boat 0,45 ltr. / 15.0 oz.	2	001.724952
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.724953
Bowl small 8,5 cm / 3.4 inch	6	001.724946
Bowl large 11 cm / 4.4 inch	6	001.724945
Party-spoon	6	001.724997
Bowl round 13 cm / 5.2 inch	4	001.724942
Bowl round 15 cm / 5.9 inch	2	001.724943
Bowl round 18 cm / 7.1 inch	2	001.724944
Bowl round 21 cm / 8.3 inch	2	001.724947
Bowl round 24 cm / 9.4 inch	2	001.724948
Oval plate flat 25 cm / 10.0 x 7.0 inch	2	001.724952
Oval plate flat 28 cm / 11.2 x 8.3 inch	2	001.724953
Oval plate flat 31 cm / 12.3 x 9.4 inch	2	001.724954
Oval plate flat 35 cm / 13.9 x 10.9 inch	2	001.724955
Egg cup with rest	6	001.724954
Salt and pepper	1	001.724961

¹ PU = Packing Unit

² Item-No refers to undecorated articles



ITEM DESCRIPTION	PU ¹	Item-No ²
Gourmet plate flat organic M5340 34 cm / 13.5 x 11.3 inch	2	001.725345
Gourmet plate flat organic M5318 29.5 cm / 11.6 x 9.3 inch	6	001.725344
Gourmet plate flat organic M5319 24 cm / 9.5 x 7.8 inch	6	001.725343
Gourmet plate flat organic M5339 19 cm / 7.5 x 6.5 inch	6	001.725342
Gourmet bowl deep organic M5317 26 cm / 9.8 x 8.5 inch	2	001.725360
Gourmet bowl deep organic M5316 20 cm / 7.8 x 6.5 inch	2	001.725349
Gourmet bowl deep organic M5374 16 cm / 6.2 x 5.4 inch	4	001.725348
Gourmet bowl deep organic M5373 12 cm / 4.7 x 3.9 inch	6	001.725347
Gourmet bowl deep organic M5372 8 cm / 3.3 x 2.6 inch	6	001.725346

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee cup organic 0,21 ltr. / 7.0 oz.	6	001.725365
Cappuccino cup organic 0,28 ltr. / 9.3 oz.	6	001.725366
Milkcoffee cup organic 0,37 ltr. / 12.3 oz.	6	001.725367
Tea cup organic 0,22 ltr. / 7.3 oz.	6	001.725368
Mug with handle organic 0,33 ltr. / 10.7 oz.	6	001.725363
Saucer (combi) organic M5375 19 cm / 7.5 x 6.5 inch	6	001.725362
Mocha cup organic 0,11 ltr. / 3.7 oz.	6	001.725369
Tea cup organic 0,15 ltr. / 5.3 oz.	6	001.725360
Saucer (combi) organic M5376 15 cm / 5.9 x 5.2 inch	6	001.725361
Sugar bowl with cover organic M5342 0,25 ltr. / 8.3 oz.	1	001.725361
Creamer organic M5341 0,25 ltr. / 8.3 oz.	1	001.725364



¹ PU = Packing Unit
² Item-No refers to undecorated articles

M

AXIM

COUP FINE DINING



ITEM DESCRIPTION	PU ¹	Item-No ²
Espresso cup M5389 0,08 ltr. / 2.7 oz.	6	001.744594
Coffee cup M5389 0,19 ltr. / 6.3 oz.	6	001.744595
Cappuccino cup M5389 0,22 ltr. / 7.3 oz.	6	001.744596
Tea cup 0,28 ltr. / 9.3 oz.	6	001.745041
Milkcoffee cup M5389 0,35 ltr. / 11.7 oz.	6	001.744597
Mug with handle M5389 0,28 ltr. / 9.3 oz.	6	001.744598
Saucer square M5387 13 x 13 cm / 5.2 x 5.2 inch	6	001.744599
Saucer square M5387 16 x 16 cm / 6.3 x 6.3 inch	6	001.744600
Saucer round M5390 13,5 cm / 5.2 inch	6	001.744601
Saucer round M5390 16,5 cm / 6.4 inch	6	001.744602
Showplate flat M5380-33-D 33 cm / 13.1 inch	4	001.729621
Plate flat coup M5380-30-D 30 cm / 12.0 inch	4	001.729615
Plate flat coup M5380-28-D 28 cm / 11.0 inch	6	001.729614
Plate flat coup M5380-26-D 26 cm / 10.3 inch	6	001.729613
Plate flat coup M5380-21,5-D 21,5 cm / 8.5 inch	6	001.729612
Plate flat coup M5380-16,5-D 16,5 cm / 6.5 inch	6	001.729611
Bowl coup M5381-28-D 28 cm / 11.0 inch	4	001.729620
Bowl coup M5381-26-D 26 cm / 10.3 inch	6	001.729619
Bowl coup M5381-23-D 23 cm / 9.2 inch	6	001.729618
Bowl coup M5381-20-D 20 cm / 7.9 inch	6	001.729617
Bowl coup M5381-14,5-D 14,5 cm / 5.7 inch	6	001.729616

¹ PU = Packing Unit
² Item-No refers to undecorated articles

ITEM DESCRIPTION	PU ¹	Item-No ²
Platter coup M5379-33x18-D 33 x 18 cm / 13.0 x 7.0 inch	2	001.733825
Platter coup M5379-40x25,5-D 40 x 25.5 cm / 16.0 x 10.2 inch	2	001.729622
Platter coup M5379-43x19-D 43 x 19 cm / 17.1 x 7.5 inch	2	001.729623
Platter coup M5379-35x11-D 35 x 11 cm / 13.9 x 4.5 inch	2	001.733824
Platter coup M5379-44x14-D 44 x 14 cm / 17.4 x 6.0 inch	2	001.729624
Duo plate 44 cm / 17.5 x 5.6 inch	2	001.732566
Bowl high 0,18 ltr. / 6.0 oz.	6	001.732565
Bowl low 0,21 ltr. / 7.0 oz.	6	001.732564
Plate flat coup square M5383 29 x 29 cm / 11.5 x 11.5 inch	4	001.743541
Plate flat coup square M5383 26 x 26 cm / 10.2 x 10.2 inch	6	001.743540
Plate flat coup square M5383 22 x 22 cm / 8.7 x 8.7 inch	6	001.743539
Plate flat coup square M5383 16,5 x 16,5 cm / 6.5 x 6.5 inch	6	001.743538
Bowl coup square M5384 26 x 26 cm / 10.2 x 10.2 inch	4	001.743546
Bowl coup square M5384 22 x 22 cm / 8.6 x 8.6 inch	6	001.743545
Bowl coup square M5384 17,5 x 17,5 cm / 6.9 x 6.9 inch	6	001.743544
Bowl coup square M5384 13 x 13 cm / 5.0 x 5.0 inch	6	001.743543
Plate flat coup rectangular M5385 35 x 20 cm / 13.9 x 8.0 inch	2	001.743542
Plate flat coup rectangular M5386 25,5 x 18 cm / 10.2 x 7.0 inch	2	001.743547
Plate flat coup rectangular M5388 38 x 14 cm / 15.2 x 5.6 inch	2	001.743548





ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,38 ltr. / 12.7 oz.	2	001.700707
Tea pot 1 0,45 ltr. / 15.0 oz.	2	001.700708
Warming plate 1039 small	1	001.700822
Tea strainer (ACCESSOIRE)	2	001.700850
Rest for tea strainer	6	001.700819
Sugar bowl 2 0,21 ltr. / 7.0 oz.	1	001.700799
Creamer 00 0,03 ltr. / 1.0 oz.	12	001.700800
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.700801
Creamer 2 0,25 ltr. / 8.3 oz.	1	001.700802
Creamer 4 0,50 ltr. / 16.7 oz.	1	001.700210
Mocha cup 0,08 ltr. / 2.7 oz.	12	001.700810
Saucer 13,5 cm / 5.3 inch	12	001.700809
Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.700812
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Coffee cup 2 0,16 ltr. / 5.3 oz.	6	001.700814
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Milkcoffee cup 0,25 ltr. / 8.3 oz.	6	001.700816
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Mug with handle 0,28 ltr. / 9.3 oz.	6	001.700820
Mocha cup non stackable 0,09 ltr. / 2.7 oz.	12	001.700806
Saucer 13,5 cm / 5.3 inch	12	001.700809
Coffee cup non stackable 0,23 ltr. / 7.7 oz.	6	001.700808
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Milkcoffee cup non stackable 0,37 ltr. / 12.3 oz.	6	001.700625
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Mug with handle non stackable 0,30 ltr. / 10.0 oz.	6	001.700821
Tea cup 0,21 ltr. / 7.0 oz.	6	001.700804
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Vase	2	001.700823
Candleholder	2	001.700824
Napkin ring	6	001.700774
Plate flat 33 cm / 13.0 inch	6	001.700773
Plate flat 31,5 cm / 12.4 inch	6	001.701737
Plate flat 29 cm / 11.4 inch	6	001.700775
Plate flat 26 cm / 10.3 inch	6	001.700772
Plate flat 22,5 cm / 9.0 inch	6	001.700774
Plate flat 19 cm / 7.7 inch	6	001.700771
Plate flat 17 cm / 6.8 inch	6	001.700770

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate deep 23 cm / 9.3 inch	6	001.700776
Salad plate 20 cm / 8.0 inch	6	001.700784
Pasta plate deep 30 cm / 11.7 inch	2	001.700785
Pasta plate deep 27 cm / 10.7 inch	2	001.700786
Soup cup 0,27 ltr. / 9.0 oz.	6	001.700778
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Eventbowl oval 5257 18 cm / 7.0 x 6.0 inch	2	001.700779
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.700787
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.700790
Butter pad small* 0,06 ltr. / 2.0 oz.	2	001.700727
Butter pad large** 0,13 ltr. / 4.3 oz.	2	001.700726
Bowl round 15 cm / 5.7 inch	4	001.700780
Bowl round 18 cm / 7.4 inch	2	001.700623
Bowl round 23 cm / 9.2 inch	2	001.700781
Bowl round 26 cm / 10.0 inch	2	001.700782
Bowl round 29 cm / 11.0 inch	2	001.700783
Relish oval deep 24 cm / 9.5 x 7.6 inch	2	001.700788
Oval plate flat 33 cm / 13.0 x 10.4 inch	2	001.700795
Oval plate flat 38 cm / 15.2 x 12.2 inch	2	001.700796
Egg cup with rest	6	001.700791
Set salt and pepper	1	001.700794
Salt shaker	2	001.700792
Pepper shaker	2	001.700793
Eventplate deep round 26 cm / 10.6 inch	2	001.712395
Eventplate flat round 25 cm / 10.0 inch	6	001.712394
Eventbowl sloping 10 cm / 3.9 inch	6	001.712396
Eventbowl sloping 18 cm / 7.2 inch	4	001.712398
Eventbowl sloping 22 cm / 8.6 inch	2	001.712399




¹ PU = Packing Unit

² Item-No refers to undecorated articles



C

UP FINE DINING

	ITEM DESCRIPTION	PU ¹	Item-No ²		ITEM DESCRIPTION	PU ¹	Item-No ²
	Coffee pot 0,38 ltr. / 13.3 oz.	2	001.742664		Plate flat coup square M5383 29 x 29 cm / 11.5 x 11.5 inch	4	001.742656
	Tea pot 0,65 ltr. / 21.6 oz.	2	001.742675		Plate flat coup square M5383 26 x 26 cm / 10.3 x 10.3 inch	6	001.742655
	Sugar bowl (LIFE) 0,26 ltr. / 8.6 oz.	1	001.737201		Plate flat coup square M5383 22 x 22 cm / 8.6 x 8.6 inch	6	001.742654
	Creamer 0,26 ltr. / 8.6 oz.	1	001.737204		Plate flat coup square M5383 16,5 x 16,5 cm / 6.5 x 6.5 inch	6	001.742653
	Mocha cup M5389 0,08 ltr. / 2.6 oz.	6	001.742665		Bowl coup square M5384 26 x 26 cm / 10.0 x 10.0 inch	4	001.742661
	Tea cup (LIFE) 0,14 ltr. / 4.6 oz.	6	001.737209		Bowl coup square M5384 22 x 22 cm / 8.6 x 8.6 inch	6	001.742660
	Coffee cup 0,19 ltr. / 6.3 oz.	6	001.742666		Bowl coup square M5384 17,5 x 17,5 cm / 6.8 x 6.8 inch	6	001.742659
	Cappuccino cup M5389 0,22 ltr. / 7.3 oz.	6	001.742667		Bowl coup square M5384 13 x 13 cm / 5.0 x 5.0 inch	6	001.742658
	Tea cup (LIFE) 0,28 ltr. / 9.3 oz.	6	001.737208		Plate flat coup rectangular M5385 35 x 20 cm / 14.0 x 8.0 inch	2	001.742657
	Milkcoffee cup M5389 0,35 ltr. / 11.6 oz.	6	001.742668		Bowl coup rectangular M5386 25,5 x 18 cm / 10.0 x 7.0 inch	2	001.742662
	Mug with handle M5389 0,28 ltr. / 9.3 oz.	6	001.742669		Platier coup rectangular M5388 38 x 14 cm / 15.0 x 6.6 inch	2	001.742663
	Mug with handle M5389 0,38 ltr. / 12.6 oz.	1	001.742670		Covered vegetable (LIFE) 3,00 ltr. / 100.0 oz.	1	001.737227
	Saucer square M5387 13 x 13 cm / 5.0 x 5.0 inch*	6	001.742671		Gravy boat (LIFE) 0,60 ltr. / 20.0 oz.	1	001.737230
	Saucer square M5387 16 x 16 cm / 6.3 x 6.3 inch**	6	001.742672		Egg cup with rest (LIFE)	6	001.737231
	Saucer round M5390 13,5 cm / 5.3 inch*	6	001.742673				
	Saucer round M5390 16,5 cm / 6.5 inch**	6	001.742674				
	Showplate flat M5380 33 cm / 13.0 inch	4	001.729476				
	Plate flat coup M5380 30 cm / 12.0 inch	6	001.729470				
	Plate flat coup M5380 28 cm / 11.0 inch	6	001.729469				
	Plate flat coup M5380 26 cm / 10.3 inch	6	001.729468				
	Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.729467				
	Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.729466				
	Bowl coup M5381 28 cm / 11.0 inch	4	001.729475				
	Bowl coup M5381 26 cm / 10.3 inch	6	001.729474				
	Bowl coup M5381 23 cm / 9.3 inch	6	001.729473				
	Bowl coup M5381 20 cm / 7.8 inch	6	001.729472				
	Bowl coup M5381 14,5 cm / 5.8 inch	6	001.729471				
	Platier coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.733789				
	Platier coup M5379 40 x 25,5 cm / 16.0 x 10.3 inch	2	001.726477				
	Platier coup M5379 43 x 19 cm / 17.3 x 7.5 inch	2	001.729478				
	Platier coup M5379 35 x 11 cm / 13.8 x 4.5 inch	2	001.733788				
	Platier coup M5379 44 x 14 cm / 17.3 x 5.5 inch	2	001.729479				
	Setplatter 44 cm / 17.5 x 5.6 inch	2	001.732630				
	Bowl high 0,18 ltr. / 6.3 oz.	6	001.732631				
	Bowl low 0,21 ltr. / 6.6 oz.	6	001.732632				

* suitable for mocha cup M5389 0,08 ltr. / 2.6 oz.,
tea cup (LIFE) 0,14 ltr. / 4.6 oz.

** suitable for all cups, except mocha cup M5389 0,08 ltr. / 2.6 oz.,
tea cup (LIFE) 0,14 ltr. / 4.6 oz.

¹ PU = Packing Unit
² Item-No refers to undecorated articles



S

AVOY

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,30 ltr. / 10.0 oz.	2	001.505082
Tea pot 1 0,40 ltr. / 13.3 oz.	2	001.505355
Tea pot 2 0,75 ltr. / 25.0 oz.	2	001.506628
Warming plate small	1	001.506040
Sugar bowl 2 0,25 ltr. / 8.3 oz.	1	001.506564
Sugar dish 8 cm / 3.2 inch	12	001.506447
Creamer 00 0,03 ltr. / 1.0 oz.	12	001.506837
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.506954
Creamer 2 0,25 ltr. / 8.3 oz.	1	001.507071
Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.506787
Saucer 1 16,4 cm / 6.5 inch	6	001.506931
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.506514
Saucer 14,5 cm / 5.7 inch	12	001.506358
Breakfast cup 0,30 ltr. / 12.0 oz.	6	001.506906
Saucer 1 16,4 cm / 6.5 inch	6	001.506931
Milkcoffee cup 0,22 ltr. / 7.3 oz.	6	001.506933
Saucer 1 16,4 cm / 6.5 inch	6	001.506931
Coffee cup non stackable 0,18 ltr. / 6.0 oz.	6	001.507968
Saucer 1 16,4 cm / 6.5 inch	6	001.506931
Mocha cup non stackable 0,09 ltr. / 3.0 oz.	12	001.506241
Saucer 14,5 cm / 5.7 inch	12	001.506358
Chocolate cup non stackable 0,22 ltr. / 7.7 oz.	6	001.507422
Saucer 1 16,4 cm / 6.5 inch	6	001.506931
Milkcoffee cup non stackable 0,37 ltr. / 12.3 oz.	6	001.507695
Saucer 1 16,4 cm / 6.5 inch	6	001.506931
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.506723
Egg cup with rest	6	001.502742
Set salt and pepper	1	001.503900
Vase	2	001.506879
Candleholder	2	001.510230
Ash tray	4	001.510113
Party-spoon	6	001.510347
Bowl sloping 8,5 cm / 3.4 inch	6	001.496374
Bowl sloping 11 cm / 4.4 inch	6	001.496881
Bowl square 9 cm / 3.5 x 3.5 inch	6	001.496491
Bowl square 11 cm / 4.8 x 4.8 inch	6	001.496764

¹ PU = Packing Unit
² Item-No refers to undecorated articles

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 34 cm / 13.4 inch	2	001.501143
Plate flat with rim 33 cm / 13.0 inch	6	001.497321
Plate flat with rim 30 cm / 12.0 inch	6	001.497165
Plate flat with rim 28 cm / 11.3 inch	6	001.497009
Plate flat with rim 26 cm / 10.4 inch	6	001.496853
Plate flat with rim 23 cm / 9.3 inch	6	001.496997
Plate flat with rim 21 cm / 8.5 inch	6	001.496541
Plate flat with rim 18 cm / 8.8 inch	6	001.496385
Plate flat with rim 16 cm / 6.5 inch	6	001.496307
Gourmetplate round 30 cm / 12.0 inch	2	001.500383
Gourmetplate round 27 cm / 10.6 inch	2	001.500519
Gourmetplate round 21 cm / 8.5 inch	6	001.501065
Gourmetplate round 18 cm / 7.3 inch	6	001.500887
Gourmetplate round 16 cm / 6.5 inch	6	001.500675
Gourmetplate round 12 cm / 4.8 inch	6	001.500831
Plate deep with rim 23 cm / 9.2 inch	6	001.497477
Salad plate deep 19 cm / 7.6 inch	6	001.500168
Soup cup 0,27 ltr. / 9.0 oz.	6	001.497789
Saucer 1 16,4 cm / 6.5 inch	6	001.506931
Everbowl 5253 18 cm / 7.0 x 4.8 inch	4	001.897323
Tureen 2,90 ltr. / 96.7 oz.	1	001.501260
Gravy boat 0,35 ltr. / 11.7 oz.	2	001.501757
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.502625
Butter pad 0,04 ltr. / 1.3 oz.	2	001.502508
Bowl round 12 cm / 4.7 inch	6	001.497906
Bowl round 14 cm / 5.5 inch	4	001.498032
Bowl round 17 cm / 6.6 inch	2	001.498218
Bowl round 20 cm / 7.8 inch	2	001.498608
Bowl round 22 cm / 8.5 inch	2	001.498698
Bowl round 24 cm / 9.3 inch	2	001.499154
Bowl round 13 cm / 5.2 inch	4	001.499934
Bowl round 15 cm / 6.0 inch	4	001.500051
Oval platter 28 cm / 11.0 x 7.6 inch	2	001.504458
Oval platter 32 cm / 12.8 x 8.7 inch	2	001.504614
Oval platter 36 cm / 14.8 x 10.0 inch	2	001.504770
Plate rectangular 36 x 14 cm / 14.2 x 5.5 inch	2	001.504146
Plate rectangular 30 x 14 cm / 11.8 x 5.5 inch	2	001.503990
Plate rectangular 23 x 14 cm / 9.1 x 5.5 inch	2	001.503834
Plate rectangular 16 x 12 cm / 6.3 x 4.7 inch	2	001.503678
Duo plate 26 cm / 10.6 x 6.0 inch	2	001.504926
Bowl square 14 cm / 5.7 x 5.7 inch	6	001.496310
Bowl square 17,5 cm / 7.0 x 7.0 inch	2	001.496496
Bowl square 22 cm / 8.7 x 8.7 inch	2	001.496622



S

AVOY

SQUARE / RECTANGULAR

ITEM DESCRIPTION

PU¹ Item-No²

Plate flat with rim square 32 cm / 12.8 x 12.8 inch	6	001.626331
Plate flat with rim square 28 cm / 11.3 x 11.3 inch	6	001.626327
Plate flat with rim square 22,5 cm / 9.0 x 9.0 inch	6	001.620703
Plate flat with rim square 17 cm / 6.5 x 6.5 inch	6	001.645154
Plate flat with rim square 24,5 cm / 9.7 x 9.7 inch	6	001.620766
Plate rectangular 40 x 27,5 cm / 15.7 x 10.7 inch	2	001.634446
Plate rectangular 35 x 24,5 cm / 13.9 x 9.6 inch	2	001.654875
Plate rectangular 29,5 x 20 cm / 11.7 x 7.8 inch	6	001.634443
Plate deep rectangular 27,5 x 20,5 cm / 11.0 x 8.0 inch	2	001.634519
Gourmet-plate deep square 27 cm / 10.7 x 10.7 inch	6	001.626336
Gourmet-plate deep square 20,5 cm / 8.1 x 8.1 inch	6	001.621075
Gourmet-plate deep square 15,5 cm / 6.1 x 6.1 inch	6	001.620951
Gourmet-plate deep square 12 cm / 4.7 x 4.7 inch	6	001.621013
Saucer square 1 18,4 cm / 6.5 x 6.5 inch*	6	001.621323
Saucer square 14 cm / 5.5 x 5.5 inch	12	001.621385

ADDITIONAL ITEMS

ITEM DESCRIPTION

PU¹ Item-No²

Plate flat JL 31,5 cm / 12.5 x 9.8 inch	6	001.620641
Plate flat JL 26,5 cm / 10.4 x 7.6 inch	6	001.620579
Dipbowl oval JL 9 cm / 4.5 x 3.5 inch	6	001.620889
Dipbowl oval JL 14 cm / 7.9 x 5.2 inch	6	001.620827



* Combi-saucer
¹ PU = Packing Unit
² Item-No refers to undecorated articles



SAVOY

»GRAND BLUE« 57513

ITEM DESCRIPTION	PU ¹	Item-No
Plate flat with rim 34 cm / 13.4 inch	2	001.749573
Plate flat with rim 30 cm / 12.0 inch	6	001.749574
Plate flat with rim 28 cm / 11.3 inch	6	001.749575
Plate flat with rim 26 cm / 10.4 inch	6	001.749576
Plate flat with rim 21 cm / 8.5 inch	6	001.749577
Plate flat with rim 18 cm / 6.5 inch	6	001.749578
Gourmetplate round 27 cm / 10.6 inch	2	001.749579
Gourmetplate round 21 cm / 8.5 inch	6	001.749580

ITEM DESCRIPTION	PU ¹	Item-No
Plate deep with rim 23 cm / 9.2 inch	6	001.749581
Salad plate deep 19 cm / 7.5 inch	6	001.749582
Plate rectangular 35 x 24,5 cm / 13.9 x 9.6 inch	2	001.749583
Plate rectangular 29,5 x 20 cm / 11.7 x 7.8 inch	6	001.749584
Saucer 1 16,4 cm / 6.5 inch	6	001.749571
Saucer 14,5 cm / 5.7 inch	12	001.749572



¹ PU = Packing Unit



ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,35 ltr. / 11.7 oz.	2	001.681319
Tea pot 1 0,45 ltr. / 15.0 oz.	2	001.681320
Warming plate 1009 small	1	001.681347
Tea strainer (ACCESSOIRE)	2	001.750850
Rest for tea strainer	6	001.686022
Sugar bowl 2 0,25 ltr. / 8.3 oz.	1	001.681223
Sugar dish 8 cm / 3.1 inch	12	001.684448
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.681326
Creamer 2 0,25 ltr. / 8.3 oz.	1	001.681224
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.681339
Saucer oval 15,5 x 14 cm / 6.1 x 5.5 inch	6	001.681762
Saucer round 13,7 cm / 5.4 inch	12	001.681227
Coffee cup 1 0,16 ltr. / 6.0 oz.	6	001.681342
Milkcoffee cup 0,25 ltr. / 8.3 oz.	6	001.681231
Mug with handle stackable 0,28 ltr. / 9.3 oz.	6	001.681232
Combi saucer oval 1 17,8 x 16,2 cm / 7.0 x 6.4 inch	6	001.681230
Combi saucer round 1 16 cm / 6.3 inch	6	001.681229
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.681225
Coffee cup 0,16 ltr. / 6.0 oz.	6	001.681336
Chocolate cup 0,25 ltr. / 8.3 oz.	6	001.681226
Milkcoffee cup 0,37 ltr. / 12.3 oz.	6	001.681337
Mug with handle 0,28 ltr. / 9.3 oz.	6	001.681346
Egg cup with rest	6	001.686025
Set salt and pepper	1	001.681313
Plate flat oval 18 cm / 7.0 x 6.4 inch	6	001.681214
Plate flat oval 24 cm / 9.4 x 8.5 inch	6	001.681215
Plate flat oval 30 cm / 11.7 x 10.8 inch	6	001.681216
Plate flat oval 34 cm / 13.5 x 12.1 inch	6	001.681217
Plate flat oval 37,5 cm / 14.9 x 13.4 inch	2	001.681752

¹ PU = Packing Unit
² Item-No refers to undecorated articles

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate deep oval 25 cm / 9.8 x 9.2 inch	6	001.681218
Plate flat round 16 cm / 6.2 inch	6	001.681210
Plate flat round 23 cm / 9.0 inch	6	001.681211
Plate flat round 26 cm / 10.3 inch	6	001.681751
Plate flat round 28 cm / 11.0 inch	6	001.681212
Plate flat round 30 cm / 11.7 inch	6	001.681213
Gourmet plate round 23 cm / 9.0 inch	6	001.681220
Gourmet plate round 27 cm / 10.6 inch	2	001.681751
Pasta plate deep round 26,5 cm / 10.4 inch	6	001.722893
Soup cup 0,27 ltr. / 9.0 oz.	6	001.681177
Saucer 1 oval 17,8 x 16,2 cm / 7.0 x 6.4 inch	6	001.681230
Saucer 1 round 16 cm / 6.3 inch	6	001.681229
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.681306
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.681309
Bowl oval 15 cm / 6.0 x 5.8 inch	6	001.683169
Bowl oval 17 cm / 6.6 x 6.1 inch	4	001.683170
Bowl oval 20 cm / 7.8 x 7.3 inch	2	001.681759
Bowl oval 24 cm / 9.4 x 8.7 inch	2	001.681760
Oval plate flat 28 cm / 11.0 x 8.2 inch	2	001.683768
Oval plate flat 31 cm / 12.2 x 9.1 inch	2	001.681221
Oval plate flat 35 cm / 13.7 x 8.7 inch	2	001.681222
Bowl 21 cm / 8.3 inch	2	001.683167





ITEM DESCRIPTION	PU ¹	Item-No ²
Eventplate flat oval 25 cm / 9.9 x 9.0 inch	6	001.681754
Eventplate deep oval 22 cm / 8.8 x 7.8 inch	4	001.681757
Eventplate deep oval 25 cm / 10.4 x 9.4 inch	2	001.681758
Eventplate deep round 26 cm / 10.2 inch	2	001.681755
Eventbowl 8,5 cm / 3.3 inch	6	001.685643
Eventbowl 10,5 cm / 4.1 inch	6	001.685644
Eventbowl 16 cm / 6.3 inch	4	001.685645
Eventbowl 21 cm / 7.9 inch	2	001.685646
Eventspoon 12 cm	6	001.685654
Eventspoon 18 cm	4	001.685655
Eventbowl sloping 14 cm / 5.6 inch	6	001.685648
Eventbowl sloping 18 cm / 7.2 inch	4	001.685650
Eventbowl sloping 22 cm / 8.7 inch	2	001.685651



¹ PU = Packing Unit
² Item-No refers to undecorated articles



C OFFE-E-MOTION

ITEM DESCRIPTION	PU ¹	Item-No ²
Creamer M5341 0,25 ltr. / 8.3 oz.	1	001.718472
Sugar bowl with cover M5342 0,26 ltr. / 8.7 oz.	1	001.718469
Mocha cup M5352 0,09 ltr. / 3.0 oz.	6	001.718477
Coffee cup M5344 0,18 ltr. / 6.0 oz.	6	001.718476
Cappuccino cup M5345 0,25 ltr. / 8.7 oz.	6	001.718482
Milkcoffee cup M5347 0,38 ltr. / 12.7 oz.	6	001.718480
Mug with handle M5348 0,30 ltr. / 10.0 oz.	6	001.718483
Mug with handle M5349 0,45 ltr. / 15.0 oz.	1	001.718484
Coffee cup low M5364 0,18 ltr. / 6.0 oz.	6	001.720153
Cappuccino cup low M5346 0,25 ltr. / 8.0 oz.	6	001.718481
Milkcoffee cup low M5365 0,37 ltr. / 12.3 oz.	6	001.720154
Saucer small M5364 17,5 cm / 6.8 x 5.7 inch*	6	001.718474
Saucer large M5350 22 cm / 8.7 x 7.3 inch**	6	001.718473

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat M5363 22 cm / 8.7 x 7.7 inch	6	001.720152
Plate flat M5351 25,5 cm / 10.0 x 9.0 inch	6	001.718462
Plate flat M5355 29 cm / 11.5 x 10.5 inch	6	001.718463
Plate flat M5366 33,5 cm / 13.2 x 11.7 inch	6	001.718464
Bowl round M5357 15 cm / 6.0 x 5.0 inch	2	001.718465
Bowl round M5358 20 cm / 8.0 x 6.9 inch	1	001.718466
Bowl round M5359 25 cm / 9.8 x 8.5 inch	1	001.718467
Bowl round M5360 0,50 ltr. / 10.3 oz.****	1	001.718485
Saucer round M5361 small 12,5 cm / 5.0 inch***	6	001.718478
Saucer round M5362 big 17,5 cm / 6.9 inch**	6	001.718479



¹ PU = Packing Unit
² Item-No refers to undecorated articles

* suitable for all cups
 ** suitable for coffee cup M5433 0,18 ltr. / 6.0 oz.
 cappuccino cup M5345 0,25 ltr. / 8.7 oz.
 milkcoffee cup M5347 0,37 ltr. / 12.7 oz.
 mug with handle M5348 0,30 ltr. / 10.0 oz.
 mug with handle M5349 0,45 ltr. / 15.0 oz.
 coffee cup low M5364 0,18 ltr. / 6.0 oz.
 cappuccino cup low M5346 0,25 ltr. / 8.0 oz.
 milkcoffee cup low M5365 0,37 ltr. / 12.3 oz.
 *** suitable for mocha cup M5352 0,09 ltr. / 3.0 oz.
 **** suitable for round M5362 large 17,5 cm / 6.9 inch



L AGUNA

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,30 ltr. / 10.0 oz.	2	001.698919
Tea pot 1 0,32 ltr. / 10.7 oz.	2	001.698922
Sugar bowl 2 0,25 ltr. / 8.3 oz.	1	001.698925
Creamer 2 0,24 ltr. / 8.0 oz.	1	001.698928
Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.698946
Saucer 1 16 cm / 6.3 inch	6	001.698945
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.698943
Saucer 13,4 cm / 5.3 inch	12	001.698942
Milkcoffee cup 0,22 ltr. / 7.3 oz.	6	001.698949
Saucer 1 16 cm / 6.3 inch	6	001.698945
Coffee cup non stackable 0,18 ltr. / 6.0 oz.	6	001.698937
Saucer 1 16 cm / 6.3 inch	6	001.698945
Chocolate cup non stackable 0,22 ltr. / 7.3 oz.	6	001.698931
Saucer 1 16 cm / 6.3 inch	6	001.698945
Egg cup with rest	6	001.702210
Set salt and pepper	1	001.702212
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.698950

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 33 cm / 13.0 inch	6	001.698899
Plate flat with rim 30 cm / 12.0 inch	6	001.698898
Plate flat with rim 28 cm / 11.0 inch	6	001.698897
Plate flat with rim 26 cm / 10.3 inch	6	001.698896
Plate flat with rim 23 cm / 9.0 inch	6	001.698895
Plate flat with rim 21 cm / 8.5 inch	6	001.698894
Plate flat with rim 17 cm / 6.6 inch	6	001.698893
Pasta bowl deep 30 cm / 12.0 inch	2	001.698910
Pasta bowl deep 27 cm / 10.6 inch	2	001.698911
Soup plate with rim 23 cm / 9.1 inch	6	001.698900
Salad plate deep 19 cm / 7.4 inch	6	001.698899
Coupsoup 19 cm / 7.4 inch	6	001.698901
Soup cup 0,27 ltr. / 9.0 oz.	6	001.698904
Saucer 1 16 cm / 6.3 inch	6	001.698945
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.702211
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.698912
Bowl round 15 cm / 6.0 inch	4	001.698905
Bowl round 18 cm / 7.0 inch	2	001.698906
Bowl round 20 cm / 8.0 inch	2	001.698907
Bowl round 23 cm / 9.0 inch	2	001.698908
Oval platter 28 cm / 11.0 x 8.1 inch	2	001.698915
Oval platter 31 cm / 12.1 x 9.2 inch	2	001.698916
Oval platter 36 cm / 13.5 x 10.4 inch	2	001.698917
Soupbowl 0,50 ltr. / 16.7 oz.	6	001.706009
Plate flat 25,5 cm / 10.0 inch	6	001.706010



¹ PU = Packing Unit
² Item-No refers to undecorated articles



LUXOR

FINE CREAM

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,30 ltr. / 10.0 oz.	2	001.522974
Tea pot 1 0,32 ltr. / 10.7 oz.	2	001.523415
Sugar bowl 2 0,25 ltr. / 8.3 oz.	1	001.523918
Creamer 00 0,03 ltr. / 1.0 oz.	12	001.524171
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.524300
Creamer 2 0,25 ltr. / 8.0 oz.	1	001.524549
Coffee pot 1 0,18 ltr. / 6.0 oz.	6	001.527826
Saucer 1 16 cm / 6.3 inch	6	001.527450
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.527132
Saucer 13,4 cm / 5.3 inch	12	001.526819
Milkcoffee cup 0,22 ltr. / 7.3 oz.	6	001.528896
Saucer 1 16 cm / 6.3 inch	6	001.527450
Coffee cup non stackable 0,18 ltr. / 6.0 oz.	6	001.526123
Saucer 1 16 cm / 6.3 inch	6	001.527450
Mocha cup non stackable 0,09 ltr. / 3.0 oz.	12	001.526564
Saucer 13,4 cm / 5.3 inch	12	001.526819
Chocolate cup non stackable 0,22 ltr. / 7.3 oz.	6	001.525179
Saucer 1 16 cm / 6.3 inch	6	001.527450
Milkcoffee cup non stackable 0,37 ltr. / 12.3 oz.	6	001.525982
Saucer 1 16 cm / 6.3 inch	6	001.527450
Egg cup with rest	6	001.520830
Set salt and pepper	1	001.521587
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.529526

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 33 cm / 12.9 inch	6	001.516108
Plate flat with rim 30 cm / 11.9 inch	6	001.515866
Plate flat with rim 28 cm / 11.1 inch	6	001.515480
Plate flat with rim 26 cm / 10.3 inch	6	001.515102
Plate flat with rim 23 cm / 9.1 inch	6	001.521448
Plate flat with rim 21 cm / 8.5 inch	6	001.514724
Plate flat with rim 17 cm / 6.6 inch	6	001.514346
Pasta bowl deep 30 cm / 11.9 inch	2	001.519440
Pasta bowl deep 27 cm / 10.6 inch	2	001.519636
Soup plate with rim 23 cm / 9.1 inch	6	001.516361
Salad plate deep 19 cm / 7.4 inch	6	001.519195
Coupsoup 19 cm / 7.5 inch	6	001.516674
Soup cup 0,27 ltr. / 9.0 oz.	6	001.517240
Saucer 1 16 cm / 6.3 inch	6	001.527450
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.520265
Gravy boat 0,09 ltr. / 3.0 oz.	4	001.637394
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.520643
Butter pad 0,05 ltr. / 1.7 oz.	2	001.520454
Bowl round 15 cm / 5.9 inch	4	001.517432
Bowl round 18 cm / 7.0 inch	2	001.517746
Bowl round 20 cm / 7.9 inch	2	001.517998
Bowl round 23 cm / 9.0 inch	2	001.518261
Bowl round 25 cm / 9.7 inch	2	001.518565
Oval platter 26 cm / 10.9 x 8.1 inch	2	001.521904
Oval platter 31 cm / 12.1 x 9.2 inch	2	001.522157
Oval platter 35 cm / 13.6 x 10.4 inch	2	001.522471
Plate flat 25,5 cm / 9.9 inch	6	001.594342

¹ PU = Packing Unit
² Item-No refers to undecorated articles



ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.173551
Tea pot 1 0,32 ltr. / 10.7 oz.	2	001.174553
Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.175238
Sugar dish 8 cm / 3.2 inch	12	001.175066
Creamer 00 0,02 ltr. / 0.7 oz.	12	001.175911
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.176231
Creamer 2 0,23 ltr. / 7.7 oz.	1	001.176561
Espresso cup 5012 0,09 ltr. / 3.0 oz.	6	001.177213
Saucer 5012 12 cm / 4.7 inch	6	001.176734
Cup 5115 0,14 ltr. / 4.7 oz.	6	001.185818
Saucer 5115 13 cm / 5.3 inch	6	001.185647
Cup 5089 0,25 ltr. / 7.7 oz.	6	001.184484
Saucer 5089 14,7 cm / 5.8 inch	6	001.183983
Cup 5092 0,35 ltr. / 12.0 oz.	6	001.185156
Saucer 5092 14,7 cm / 6.3 inch	6	001.184815



¹ PU = Packing Unit
² Item-No refers to undecorated articles

ITEM DESCRIPTION	PU ¹	Item-No ²
Espresso cup 1132 0,09 ltr. / 3.0 oz.	6	001.173516
Saucer 1132 11,8 cm / 4.6 inch	6	001.177855
Cup 1163 0,18 ltr. / 6.0 oz.	6	001.188318
Saucer 1163 14,7 cm / 5.8 inch	6	001.187817
Cappuccino cup 1131 0,22 ltr. / 7.3 oz.	6	001.188971
Saucer 1131 14,7 cm / 5.8 inch	6	001.188312
Cup 5118 0,29 ltr. / 9.7 oz.	6	001.185838
Saucer 5118 15,9 cm / 6.3 inch	6	001.185837
Cup 1164 0,37 ltr. / 12.3 oz.	6	001.189312
Saucer 1164 15,9 cm / 6.3 inch	6	001.188651
Cup 5041 0,50 ltr. / 16.7 oz.	6	001.185487
Saucer 5041 19,1 cm / 7.5 inch	6	001.185327
Cup without handle 5041 0,50 ltr. / 16.7 oz.	6	001.185989
Mug with handle 5005 0,25 ltr. / 8.3 oz.	6	001.190944
Mug with handle 05 0,26 ltr. / 8.7 oz.	6	001.189972
Mug with handle 08 0,31 ltr. / 10.3 oz.	6	001.190132
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.189812
Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.181815
Saucer 1 16,2 cm / 6.4 inch	6	001.181154
Coffee cup 2 0,16 ltr. / 5.3 oz.	6	001.182624
Saucer 2 13,7 cm / 5.4 inch	6	001.182305
Coffee cup 3 0,20 ltr. / 6.7 oz.	6	001.187494
Saucer 1 16,2 cm / 6.4 inch	6	001.181154
Chocolate cup 0,23 ltr. / 7.3 oz.	6	001.190624
Saucer 1 16,2 cm / 6.4 inch	6	001.181154
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.180662
Saucer 13,6 cm / 5.4 inch	12	001.180001
Mocha cup high 0,08 ltr. / 2.7 oz.	12	001.179838
Saucer 13,6 cm / 5.4 inch	12	001.180001
Milkcoffee cup 0,25 ltr. / 8.3 oz.	6	001.183298
Saucer 1 16,2 cm / 6.4 inch	6	001.181154



MERAN

BASIC

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 33 cm / 13.0 inch	6	001.157857
Plate flat with rim 30 cm / 12.0 inch	6	001.157014
Plate flat with rim 28 cm / 11.0 inch	6	001.156022
Plate flat with rim 26 cm / 10.2 inch	6	001.155188
Plate flat with rim 23 cm / 9.0 inch	6	001.154854
Plate flat with rim 20 cm / 8.0 inch	6	001.154013
Plate flat with rim 17 cm / 6.8 inch	6	001.153180
Plate flat with rim 15 cm / 6.0 inch	6	001.690815
Plate deep with rim 23 cm / 8.9 inch	6	001.160941
Pasta plate oval 32 cm / 12.6 x 10.3 inch	1	001.166267
Pasta plate 5009 30 cm / 11.8 inch	2	001.167730
Pasta plate 5064 27 cm / 10.6 inch	2	001.167068
Pasta plate 5008 23 cm / 9.0 inch	6	001.167388
Salad plate 19 cm / 7.6 inch	6	001.166589
Tureen 3,00 ltr. / 100.0 oz.	1	001.168093
Soup cup 0,28 ltr. / 9.3 oz.	6	001.162264
Saucer 1 16,2 cm / 6.4 inch	6	001.181154
Gravy boat 0,40 ltr. / 13.3 oz.	2	001.168255
Butter pad 0,04 ltr. / 1.3 oz.	2	001.168894
Gravy boat 0,10 ltr. / 3.3 oz.	4	001.169226

ITEM DESCRIPTION	PU ¹	Item-No ²
Bowl round 13 cm / 5.0 inch	6	001.162949
Bowl round 15 cm / 5.8 inch	4	001.163610
Bowl round 16 cm / 6.3 inch	2	001.164123
Bowl round 20 cm / 7.9 inch	2	001.164637
Bowl round 23 cm / 9.0 inch	2	001.165287
Bowl round 25 cm / 10.0 inch	2	001.165778
Oval plate flat 25 cm / 10.0 x 6.4 inch	2	001.171554
Oval plate flat 28 cm / 11.0 x 8.3 inch	2	001.172066
Oval plate flat 31 cm / 12.2 x 9.1 inch	2	001.172547
Oval plate flat 35 cm / 13.8 x 10.6 inch	2	001.173049
Vase	4	001.193048
Candleholder	2	001.194062
Ash tray	4	001.193730
Set salt and pepper	1	001.171063
Egg cup with rest	6	001.169716



¹ PU = Packing Unit
² Item-No refers to undecorated articles



ITEM DESCRIPTION	PU ¹	Item-No ²
Coup plate flat oval 5234 21 cm / 8.3 x 7.5 inch	6	001.004414
Coup plate flat oval 5195 25 cm / 9.8 x 9.0 inch	6	001.160460
Coup plate flat oval 5233 27 cm / 10.6 x 9.7 inch	6	001.159980
Coup plate flat oval 5192 29 cm / 11.9 x 11.0 inch	6	001.159950
Coup plate flat oval 5235 34 cm / 13.4 x 12.0 inch	2	001.004415
Fitness plate 5248 34 cm / 13.4 x 12.0 inch	2	001.659439
Fitness plate 5258 34 cm / 13.4 x 12.0 inch	2	001.705925
Coup plate flat 5196 15,5 cm / 6.2 inch	6	001.158540
Coup plate flat 5197 17,5 cm / 7.0 inch	6	001.159020
Coup plate flat round 5208 21,5 cm / 8.5 inch	6	001.618397
Coup plate flat round 5209 25,5 cm / 10.0 inch	6	001.618586
Coup plate flat round 5210 29 cm / 11.5 inch	6	001.618775
Coup plate deep 5236 14,5 cm / 5.7 inch	6	001.004416
Coup plate deep 5237 23 cm / 9.0 inch	6	001.004417
Coup plate deep 5211 29 cm / 11.6 inch	6	001.618964

ITEM DESCRIPTION	PU ¹	Item-No ²
Bowl 1060 0,60 ltr. / 20.0 oz.	6	001.004428
Bowl oval M5307 9 cm / 3.3 x 2.6 inch	6	001.722208
Bowl oval M5306 12 cm / 4.7 x 3.7 inch	6	001.722213
Soup bowl oval 5238 16 cm / 6.0 x 5.3 inch	4	001.004418
Bowl oval 5239 21 cm / 8.3 x 7.0 inch	2	001.004419
Bowl oval 5240 25,5 cm / 10.0 x 8.5 inch	2	001.004420
Oval platter deep 5231 18,5 cm / 7.2 x 4.7 inch	2	001.708048
Oval platter 5230 23,5 cm / 9.3 x 6.0 inch	2	001.708047
Espresso cup 5241 0,09 ltr. / 3.0 oz.	6	001.004427
Saucer 5241 12,7 cm / 5.0 inch	6	001.004426
Coffee cup 5242 0,20 ltr. / 6.7 oz.	6	001.004425
Saucer 5242/5243 16,2 cm / 6.4 inch	6	001.004424
Cappuccino cup 5243 0,25 ltr. / 8.3 oz.	6	001.004423
Saucer 5242/5243 16,2 cm / 6.4 inch	6	001.004424
Mug Diva 5156 0,35 ltr. / 13.3 oz.	6	001.004429
Saucer 5156 17,5 cm / 7.0 inch	6	001.004421



¹ PU = Packing Unit
² Item-No refers to undecorated articles



ITEM DESCRIPTION	PU ¹	Item-No ²
Gourmet-plate flat organic M5340 34 cm / 13.4 x 11.0 inch	2	001.725323
Gourmet-plate flat organic M5318 29,5 cm / 11.5 x 9.3 inch	6	001.725322
Gourmet-plate flat organic M5319 24 cm / 9.4 x 7.7 inch	6	001.725321
Gourmet-plate flat organic M5339 19 cm / 7.5 x 6.5 inch	6	001.725320
Gourmet-bowl deep organic M5317 25 cm / 9.8 x 8.7 inch	2	001.725328
Gourmet-bowl deep organic M5316 20 cm / 7.7 x 6.4 inch	2	001.725327
Gourmet-bowl deep organic M5374 15 cm / 6.2 x 5.4 inch	4	001.725326
Gourmet-bowl deep organic M5373 12 cm / 4.8 x 4.0 inch	6	001.725325
Gourmet-bowl deep organic M5372 8 cm / 3.1 x 2.7 inch	6	001.725324

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee cup organic 0,21 ltr. / 7.0 oz.	6	001.725333
Cappuccino cup organic 0,28 ltr. / 9.5 oz.	6	001.725334
Milkcoffee cup organic 0,37 ltr. / 12.3 oz.	6	001.725335
Tea cup organic 0,22 ltr. / 7.3 oz.	6	001.725336
Mug with handle organic 0,33 ltr. / 10.7 oz.	6	001.725341
Saucer organic M5375 19 cm / 7.5 x 6.5 inch	6	001.725340
Mocha cup organic 0,11 ltr. / 3.7 oz.	6	001.725337
Tea cup organic 0,16 ltr. / 5.3 oz.	6	001.725338
Saucer organic M5376 15 cm / 6.0 x 5.2 inch	6	001.725339
Sugar bowl with lid organic M5342 0,25 ltr. / 8.3 oz.	1	001.725329
Creamer organic M5341 0,25 ltr. / 8.3 oz.	1	001.725332

¹ PU = Packing Unit
² Item-No refers to undecorated articles





ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1,20 ltr. / 40.7 oz.	1	001.015914
Sugar bowl 0,28 ltr. / 9.3 oz.	1	001.015915
Creamer 0,25 ltr. / 8.3 oz.	1	001.015916
Coffee cup 0,22 ltr. / 7.3 oz.	6	001.015918
Cappuccino cup 0,23 ltr. / 8.3 oz.	6	001.015923
Milk coffee cup 0,37 ltr. / 12.3 oz.	6	001.015922
Saucer round 17 cm / 6.7 inch	6	001.015927
Saucer square 19,5 x 16,5 cm / 7.8 x 6.5 inch	6	001.015928
Mocha cup 0,09 ltr. / 3.0 oz.	6	001.015921
Saucer round 14,5 cm / 5.7 inch	6	001.015925
Saucer square 15 x 13,5 cm / 6.3 x 5.3 inch	6	001.015926
Mug with handle 0,34 ltr. / 11.3 oz.	6	001.015924
Egg cup with rest	6	001.015909
Espresso cup 5241 0,09 ltr. / 3.0 oz.	6	001.659437
Coffee cup 5242 0,20 ltr. / 6.7 oz.	6	001.659436
Cappuccino cup 5243 0,25 ltr. / 8.3 oz.	6	001.659435
Saucer square Hotel 19,5 cm / 7.8 x 6.5 inch	6	001.659434
Saucer square Hotel 10,0 cm / 6.3 x 5.3 inch	6	001.659433

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat square 34,5 x 30 cm / 13.6 x 12.0 inch	2	001.015899
Plate flat square 30 x 26 cm / 11.7 x 10.3 inch	6	001.015900
Plate flat square 25 x 21 cm / 10.0 x 8.4 inch	6	001.015898
Plate flat square 20 x 16,5 cm / 7.8 x 6.5 inch	6	001.680685
Bowl square 27 x 23 cm / 10.6 x 9.0 inch	1	001.685522
Bowl square 23,5 cm / 9.3 x 8.0 inch	1	001.685521
Bowl square 19,5 x 17 cm / 7.8 x 6.7 inch	1	001.685520
Plate flat 33,5 cm / 13.2 inch	1	001.015893
Plate flat 28 cm / 11.0 inch	6	001.015894
Plate flat 23 cm / 9.0 inch	6	001.015897
Plate flat 20 cm / 7.9 inch	6	001.015896
Pasta plate deep 27 cm / 10.7 inch	2	001.015906
Plate deep 22,5 cm / 9.0 inch	6	001.015905
Bowl round 19 cm / 7.4 inch	6	001.015901
Plate 35 x 26 cm / 13.8 x 10.4 inch	1	001.015912
Plate 32 x 26,5 cm / 12.5 x 10.4 inch	1	001.015911
Bowl round 30,5 cm / 12.0 inch	1	001.015905
Bowl round 25 cm / 10.0 inch	1	001.015904
Bowl round 20 cm / 8.0 inch	1	001.015903
Bowl round 15 cm / 6.0 inch	2	001.015902
Tureen with lid 3,0 ltr. / 102.0 oz.	1	001.015907
Gravy boat 0,55 ltr. / 18.3 oz.	1	001.015908



¹ PU = Packing Unit
² Item-No refers to undecorated articles



SALZBURG

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,34 ltr. / 11.3 oz.	2	001.606990
Coffee pot 3 0,66 ltr. / 22.0 oz.	2	001.607216
Tea pot 1 0,33 ltr. / 11.0 oz.	2	001.607901
Sugar bowl 2 0,20 ltr. / 6.7 oz.	1	001.608802
Sugar dish 8 cm / 3.2 inch	12	001.608485
Creamer 0 0,04 ltr. / 1.3 oz.	12	001.606094
Creamer 1 0,16 ltr. / 5.0 oz.	1	001.606538
Creamer 2 0,23 ltr. / 7.7 oz.	1	001.609754
Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.611113
Saucer 1 14,5 cm / 5.7 inch	6	001.610860
Chocolate cup non stackable 0,22 ltr. / 7.3 oz.	6	001.613610
Saucer 1 14,5 cm / 5.7 inch	6	001.610860
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.610585
Saucer 12 cm / 4.7 inch	12	001.610330
Milkcoffee cup 0,25 ltr. / 8.3 oz.	6	001.612504
Saucer 1 14,5 cm / 5.7 inch	6	001.610860
Egg cup with rest	6	001.604895
Set salt and pepper	1	001.605538
Mug with handle 06 0,25 ltr. / 8.3 oz.	12	001.613256

ITEM DESCRIPTION	PU ¹	Item-No ²
Sugar packed holder	6	001.608773
Plate flat with rim 30 cm / 12.0 inch	6	001.600942
Plate flat with rim 27 cm / 10.5 inch	6	001.600653
Plate flat with rim 25 cm / 9.8 inch	6	001.600365
Plate flat with rim 21 cm / 8.3 inch	6	001.600047
Plate flat with rim 19 cm / 7.5 inch	6	001.599759
Plate flat with rim 17 cm / 6.7 inch	6	001.599434
Plate flat with rim 15 cm / 6.0 inch	6	001.599318
Plate deep 23 cm / 9.0 inch	6	001.601325
Salad plate 19 cm / 7.5 inch	6	001.603822
Coupsoup 19 cm / 7.5 inch	6	001.601607
Pasta plate deep 30 cm / 11.9 inch	2	001.604031
Soup cup 0,26 ltr. / 9.3 oz.	6	001.602242
Saucer 16,2 cm / 6.4 inch	6	001.601053
Tureen 3,00 ltr. / 100.0 oz.	1	001.604126
Gravy boat 0,55 ltr. / 18.3 oz.	2	001.604270
Gravy boat 0,10 ltr. / 3.3 oz.	4	001.604515
Butter pad 0,06 ltr. / 2.0 oz.	2	001.604450
Bowl round 13 cm / 5.0 inch	6	001.602488
Bowl round 15 cm / 6.0 inch	4	001.602689
Bowl round 18 cm / 7.0 inch	2	001.602021
Bowl round 20 cm / 8.0 inch	2	001.603138
Bowl round 23 cm / 9.0 inch	2	001.603390
Bowl round 25 cm / 9.8 inch	2	001.603606
Oval platter 28 cm / 11.0 x 7.0 inch	2	001.605718
Oval platter 31 cm / 12.5 x 8.4 inch	2	001.605970
Oval platter 35 cm / 14.0 x 9.5 inch	2	001.606215
Oval platter 38 cm / 15.0 x 10.4 inch	2	001.606467
Oval platter 24 cm / 9.5 x 5.6 inch	2	001.604011
Candleholder 941	2	001.616203

¹ PU = Packing Unit
² Item-No refers to undecorated articles



ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,35 ltr. / 11.7 oz.	2	001.539906
Tea pot 1 0,35 ltr. / 11.7 oz.	2	001.540481
Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.540795
Sugar dish 9 cm / 3.5 inch	12	001.540650
Creamer 1 0,16 ltr. / 5.3 oz.	1	001.541154
Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.541945
Saucer 1 15 cm / 6.0 inch	6	001.541802
Chocolate cup 0,23 ltr. / 7.3 oz.	6	001.543407
Saucer 1 15 cm / 6.0 inch	6	001.541802
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.541679
Saucer 12 cm / 4.8 inch	12	001.541584
Milkcoffee cup 0,25 ltr. / 8.3 oz.	6	001.542497
Saucer 1 15 cm / 6.0 inch	6	001.541802
Set salt and pepper	1	001.539326
Mug with handle 0,30 ltr. / 10.0 oz.	6	001.543168

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 30 cm / 12.0 inch	6	001.537146
Plate flat with rim 27 cm / 10.6 inch	6	001.537002
Plate flat with rim 25 cm / 9.9 inch	6	001.536858
Plate flat with rim 21 cm / 8.2 inch	6	001.536714
Plate flat with rim 19 cm / 7.5 inch	6	001.536570
Plate flat with rim 17 cm / 6.8 inch	6	001.536426
Plate flat with rim 15 cm / 6.0 inch	6	001.536282
Plate deep with rim 23 cm / 9.0 inch	6	001.537289
Plate deep with rim 19 cm / 7.5 inch	6	001.538465
Soup cup 0,30 ltr. / 10.0 oz.	6	001.537624
Saucer 1 15 cm / 5.9 inch	6	001.541802
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.538656
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.538824
Butter pad 0,04 ltr. / 1.3 oz.	2	001.538751
Bowl round 13 cm / 5.1 inch	6	001.537721
Bowl round 15 cm / 6.0 inch	4	001.537841
Bowl round 18 cm / 7.1 inch	2	001.537962
Bowl round 20 cm / 7.7 inch	2	001.538106
Bowl round 23 cm / 9.0 inch	2	001.538249
Bowl round 25 cm / 9.9 inch	2	001.538368
Oval platter 28 cm / 10.6 x 7.1 inch	2	001.539378
Oval platter 31 cm / 12.0 x 8.1 inch	2	001.539522
Oval platter 35 cm / 13.6 x 9.3 inch	2	001.539665
Oval platter 38 cm / 14.6 x 9.9 inch	2	001.539785
Oval platter 24 cm / 9.3 x 5.0 inch	2	001.539042

¹ PU = Packing Unit
² Item-No refers to undecorated articles



C

COUP FINE DINING

»FASHION«





	ITEM DESCRIPTION	PU ¹	Item-No	Airbrushed	Textured
	Bowl coup M5381 28 cm / 11.0 inch	4	001.742482 ¹ 001.742504 ¹	●	
	Bowl coup M5381 26 cm / 10.3 inch	6	001.742485 ¹ 001.742503 ¹	●	
	Bowl coup M5381 23 cm / 9.2 inch	6	001.742480 ¹ 001.742502 ¹	●	
	Bowl coup M5381 20 cm / 7.9 inch	6	001.742489 ¹ 001.742501 ¹	●	
	Bowl coup M5381 14.5 cm / 5.7 inch	6	001.742488 ¹ 001.742500 ¹	●	
	Platter coup M5379 33 x 18 cm 13.0 x 7.0 inch	2	001.742470 ¹ 001.742512 ¹		●
	Platter coup M5379 40 x 25.5 cm 15.9 x 10.2 inch	2	001.742480 ¹ 001.742508 ¹		●
	Platter coup M5379 43 x 19 cm 17.1 x 7.5 inch	2	001.742487 ¹ 001.742509 ¹		●
	Platter coup M5379 35 x 11 cm 13.9 x 4.5 inch	2	001.742488 ¹ 001.742511 ¹		●
	Platter coup M5379 44 x 14 cm 17.4 x 5.6 inch	2	001.742488 ¹ 001.742510 ¹		●
	Setplatter 44 cm / 17.5 x 5.6 inch	2	001.742472 ¹ 001.742514 ¹		●
	Bowl high 0,18 ltr. / 6.3 oz.	6	001.742484 ¹ 001.742509 ¹	●	
	Bowl low 0,21 ltr. / 6.7 oz.	6	001.742483 ¹ 001.742509 ¹	●	

¹ PU = Padding Unit

Airbrushed Textured ² «old rose» 57270

Airbrushed Textured ³ «turquoise» 57271



C OUP FINE DINING

»FASHION«

ITEM DESCRIPTION PU¹ Item-No. Airbrushed Textured

	Coffee pot 0,38 ltr. / 13.3 oz.	2	001.742567* 001.742589* 001.742641*	•	
	Tea pot 0,65 ltr. / 21.7 oz.	2	001.742568* 001.742610* 001.742652*	•	
	Sugar bowl 0,25 ltr. / 8.7 oz. (LIFE)	1	001.744641* 001.744648* 001.744655*	•	
	Creamer 0,25 ltr. / 8.7 oz. (LIFE)	1	001.744642* 001.744649* 001.744656*	•	
	Mocha cup M5389 0,08 ltr. / 2.7 oz.	6	001.742568* 001.742600* 001.742642*	•	
	Tea cup (LIFE) 0,14 ltr. / 4.7 oz.	6	001.744639* 001.744646* 001.744653*	•	
	Coffee cup M5389 0,19 ltr. / 6.3 oz.	6	001.742569* 001.742601* 001.742643*	•	
	Cappuccino cup M5389 0,22 ltr. / 7.3 oz.	6	001.742560* 001.742602* 001.742644*	•	
	Tea cup (LIFE) 0,23 ltr. / 8.3 oz.	6	001.744640* 001.744647* 001.744654*	•	
	Milkcoffee cup M5389 0,35 ltr. / 11.7 oz.	6	001.742561* 001.742603* 001.742645*	•	

ITEM DESCRIPTION PU¹ Item-No. Airbrushed Textured

	Mug with handle M5389 0,28 ltr. / 9.3 oz.	6	001.742562* 001.742604* 001.742646*	•	
	Mug with handle M5389 0,38 ltr. / 12.7 oz.	1	001.742563* 001.742605* 001.742647*	•	
	Saucer square small M5387 13 x 13 cm 5.2 x 5.2 inch*	6	001.742564* 001.742606* 001.742648*		•
	Saucer square big M5387 16 x 16 cm 6.3 x 6.3 inch**	6	001.742565* 001.742607* 001.742649*		•
	Saucer round small M5390 13,5 cm / 5.2 inch**	6	001.742566* 001.742608* 001.742650*		•
	Saucer round big M5390 16,5 cm / 6.5 inch**	6	001.742567* 001.742609* 001.742651*		•
	Showplate flat M5380 33 cm / 13.1 inch	4	001.742549* 001.742581* 001.742633*		•
	Plate flat coup M5380 30 cm / 12.0 inch	6	001.742531* 001.742573* 001.742615*		•
	Plate flat coup M5380 28 cm / 11.1 inch	6	001.742530* 001.742572* 001.742614*		•
	Plate flat coup M5380 26 cm / 10.3 inch	6	001.742529* 001.742571* 001.742613*		•

ITEM DESCRIPTION PU¹ Item-No. Airbrushed Textured

	Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.742528* 001.742570* 001.742612*		•
	Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.742527* 001.742569* 001.742611*		•
	Bowl coup M5381 28 cm / 11.0 inch	4	001.742540* 001.742588* 001.742630*	•	
	Bowl coup M5381 26 cm / 10.3 inch	6	001.742545* 001.742587* 001.742629*	•	
	Bowl coup M5381 23 cm / 9.2 inch	6	001.742544* 001.742586* 001.742628*	•	
	Bowl coup M5381 20 cm / 7.9 inch	6	001.742543* 001.742585* 001.742627*	•	
	Bowl coup M5381 14,5 cm / 5.7 inch	6	001.742542* 001.742584* 001.742626*	•	
	Platter coup M5379 33 x 18 cm 13.0 x 7.0 inch	2	001.742554* 001.742590* 001.742638*		•
	Platter coup M5379 40 x 25,5 cm 15.9 x 10.2 inch	2	001.742550* 001.742582* 001.742634*		•
	Platter coup M5379 43 x 19 cm 17.1 x 7.5 inch	2	001.742551* 001.742583* 001.742635*		•
	Platter coup M5379 35 x 11 cm 13.9 x 4.5 inch	2	001.742553* 001.742585* 001.742637*		•
	Platter coup M5379 44 x 14 cm 17.4 x 5.6 inch	2	001.742552* 001.742584* 001.742636*		•
	Serving platter 44 cm / 17.5 x 5.6 inch	2	001.742550* 001.742588* 001.742640*		•
	Bowl high 0,18 ltr. / 6.3 oz.	6	001.742548* 001.742590* 001.742632*	•	
	Bowl low 0,21 ltr. / 6.7 oz.	6	001.742547* 001.742589* 001.742631*	•	

* suitable for mocha cup M5389 0,08 ltr. / 2.7 oz.,
tea cup 0,14 ltr. / 4.7 oz. (LIFE)

** suitable for all cups, except mocha cup M5389 0,08 ltr. / 2.7 oz.,
tea cup 0,14 ltr. / 4.7 oz. (LIFE)

¹ PU = Packing Unit

C OUP FINE DINING

»FASHION«

ITEM DESCRIPTION PU¹ Item-No. Airbrushed Textured


	Plate flat coup square M5383 29 x 29 cm 11.5 x 11.5 inch	4	001.742535* 001.742577* 001.742619*		•
	Plate flat coup square M5383 26 x 26 cm 10.2 x 10.2 inch	6	001.742534* 001.742576* 001.742618*		•
	Plate flat coup square M5383 22 x 22 cm 8.7 x 8.7 inch	6	001.742533* 001.742575* 001.742617*		•
	Plate flat coup square M5383 16,5 x 16,5 cm 6.5 x 6.5 inch	6	001.742532* 001.742574* 001.742616*		•
	Bowl coup square M5384 26 x 26 cm 10.2 x 10.2 inch	4	001.742540* 001.742582* 001.742624*	•	
	Bowl coup square M5384 22 x 22 cm 8.6 x 8.6 inch	6	001.742539* 001.742581* 001.742623*	•	
	Bowl coup square M5384 17,5 x 17,5 cm 6.9 x 6.9 inch	6	001.742538* 001.742580* 001.742622*	•	
	Bowl coup square M5384 13 x 13 cm 5.0 x 5.0 inch	6	001.742537* 001.742579* 001.742621*	•	
	Plate flat coup rectangular M5385 35 x 20 cm 14.0 x 8.0 inch	2	001.742538* 001.742578* 001.742620*		•
	Bowl coup rectangular M5386 25,5 x 18 cm 10.2 x 7.0 inch	2	001.742541* 001.742583* 001.742629*	•	
	Platter coup rectangular M5388 38 x 14 cm 15.2 x 5.5 inch	2	001.742555* 001.742597* 001.742639*		•
	Tureen with lid 3,00 ltr. / 100.0 oz. (LIFE)	1	001.744638* 001.744643* 001.744650*	•	
	Gravy boat 0,60 ltr. / 20.0 oz. (LIFE)	1	001.744637* 001.744644* 001.744651*	•	
	Egg cup with rest (LIFE)	6	001.744638* 001.744645* 001.744652*	•	



4 »grey« 57272



5 »anthracite« 57273



6 »black« 57350



C

COUP FINE DINING

»KARMA« 57423

ITEM DESCRIPTION	PU ¹	Item-No Karma 57423	Full decoration	Partial decoration
 Coffee pot 0,38 ltr. / 13.3 oz.	2	001.744569		●
 Tea pot 0,65 ltr. / 21.7 oz.	2	001.744570		●
 Sugar bowl (LIFE) 0,26 ltr. / 8.7 oz.	1	001.744571		●
 Creamer (LIFE) 0,29 ltr. / 8.7 oz.	1	001.744572		●
 Mocha cup M5389 0,09 ltr. / 2.7 oz.	6	001.744573		●
 Tea cup (LIFE) 0,14 ltr. / 4.7 oz.	6	001.744587		●
 Coffee cup M5389 0,19 ltr. / 6.3 oz.	6	001.744574		●
 Cappuccino cup M5389 0,22 ltr. / 7.3 oz.	6	001.744575		●
 Tea cup (LIFE) 0,29 ltr. / 8.3 oz.	6	001.744588		●
 Milkcoffee cup M5389 0,35 ltr. / 11.7 oz.	6	001.744576		●

ITEM DESCRIPTION	PU ¹	Item-No Karma 57423	Full decoration	Partial decoration
 Mug with handle M5389 0,26 ltr. / 9.3 oz.	6	001.744577		●
 Mug with handle M5389 0,38 ltr. / 12.7 oz.	1	001.744578		●
 Saucer square small M5387 13 x 13 cm 5.2 x 5.2 inch*	6	001.744579	●	
 Saucer square big M5387 16 x 16 cm 6.3 x 6.3 inch**	6	001.744580	●	
 Saucer round small M5380 13,5 cm / 5.2 inch**	6	001.744581	●	
 Saucer round big M5380 16,5 cm / 6.5 inch**	6	001.744582	●	
 Showplate flat M5380 33 cm / 13.1 inch	4	001.744539	●	
 Plate flat coup M5380 30 cm / 12.0 inch	6	001.744540	●	
 Plate flat coup M5380 28 cm / 11.1 inch	6	001.744541	●	
 Plate flat coup M5380 26 cm / 10.3 inch	6	001.744542	●	

C

COUP FINE DINING

»KARMA« 57423

ITEM DESCRIPTION	PU ¹	Item-No Karma 57423	Full decoration	Partial decoration
 Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.744543	●	
 Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.744544	●	
 Bowl coup M5381 28 cm / 11.0 inch	4	001.744545		●
 Bowl coup M5381 26 cm / 10.3 inch	6	001.744546		●
 Bowl coup M5381 23 cm / 9.2 inch	6	001.744547		●
 Bowl coup M5381 20 cm / 7.9 inch	6	001.744548		●
 Bowl coup M5381 14,5 cm / 5.7 inch	6	001.744549		●
 Platter coup M5379 33 x 18 cm 13.0 x 7.0 inch	2	001.744550	●	
 Platter coup M5379 40 x 25,5 cm 15.9 x 10.2 inch	2	001.744551	●	
 Platter coup M5379 43 x 19 cm 17.1 x 7.5 inch	2	001.744552	●	
 Platter coup M5379 35 x 11 cm 13.9 x 4.5 inch	2	001.744553	●	
 Platter coup M5379 44 x 14 cm 17.4 x 5.5 inch	2	001.744554	●	
 Setplatter 44 cm 17.5 x 5.6 inch	2	001.744555	●	
 Bowl high 0,16 ltr. / 6.3 oz.	6	001.744556		●
 Bowl low 0,21 ltr. / 6.7 oz.	6	001.744557		●

ITEM DESCRIPTION	PU ¹	Item-No Karma 57423	Full decoration	Partial decoration
 Plate flat coup square M5383 29 x 29 cm 11.5 x 11.5 inch	4	001.744558	●	
 Plate flat coup square M5383 26 x 26 cm 10.2 x 10.2 inch	6	001.744559	●	
 Plate flat coup square M5383 22 x 22 cm 8.7 x 8.7 inch	6	001.744560	●	
 Plate flat coup square M5383 16,5 x 16,5 cm 6.5 x 6.5 inch	6	001.744561	●	
 Bowl coup square M5384 26 x 26 cm 10.2 x 10.2 inch	4	001.744562		●
 Bowl coup square M5384 22 x 22 cm 8.6 x 8.6 inch	6	001.744563		●
 Bowl coup square M5384 17,5 x 17,5 cm 6.9 x 6.9 inch	6	001.744564		●
 Bowl coup square M5384 13 x 13 cm 5.0 x 5.0 inch	6	001.744565		●
 Plate flat coup rectangular M5385 35 x 20 cm 14.0 x 8.0 inch	2	001.744566	●	
 Bowl coup rectangular M5388 25,5 x 18 cm 10.2 x 7.0 inch	2	001.744567		●
 Platter coup rectangular M5388 38 x 14 cm 15.2 x 5.6 inch	2	001.744568	●	
 Tureen with lid 3,00 ltr. / 100.0 oz. (LIFE)	1	001.744584		●
 Gravy boat 0,60 ltr. / 20.0 oz. (LIFE)	1	001.744585		●
 Egg cup with rest (LIFE)	6	001.744586	●	



2 Full decoration
3 Partial decoration

* suitable for mocha cup M5389 0,08 ltr. / 2.7 oz.,
tea cup 0,14 ltr. / 4.7 oz. (LIFE)
** suitable for all cups, except mocha cup M5389 0,08 ltr. / 2.7 oz., tea cup
0,14 ltr. / 4.7 oz. (LIFE)


¹ PU = Packing Unit



C OUP FINE DINING

»FANTASTIC«

ITEM DESCRIPTION	PU ¹	Item-No	ITEM DESCRIPTION	PU ¹	Item-No
Showplate flat M5380 33 cm / 13.0 inch	4	001.736027 001.736071 001.736075 001.736079 001.749512	Bowl coup M5381 28 cm / 11.0 inch	4	001.736069 001.736070 001.736074 001.736078 001.749519
Plate flat coup M5380 30 cm / 12.0 inch	6	001.736065 001.736069 001.736073 001.736077 001.749513	Bowl coup M5381 26 cm / 10.3 inch	6	001.736069 001.736070 001.736074 001.736078 001.749519
Plate flat coup M5380 28 cm / 11.0 inch	6	001.736062 001.736072 001.736076 001.736078 001.749514	Bowl coup M5381 23 cm / 9.2 inch	6	001.736069 001.736070 001.736074 001.736078 001.749519
Plate flat coup M5380 26 cm / 10.3 inch	6	001.736064 001.736068 001.736072 001.736076 001.749515	Bowl coup M5381 20 cm / 7.9 inch	6	001.736069 001.736070 001.736074 001.736078 001.749519
Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.736061 001.736071 001.736075 001.736079 001.749516	Bowl coup M5381 14,5 cm / 5.7 inch	6	001.736069 001.736070 001.736074 001.736078 001.749519
Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.736060 001.736070 001.736074 001.736078 001.749517			



C OUP FINE DINING

»FANTASTIC«

ITEM DESCRIPTION	PU ¹	Item-No
Platter coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.736293 001.736323 001.736327 001.736331 001.749523
Platter coup M5379 40 x 25,5 cm / 16.0 x 10.2 inch	2	001.736294 001.736319 001.736323 001.736327 001.749524
Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.736290 001.736320 001.736324 001.736328 001.749525
Platter coup M5379 35 x 11 cm / 13.9 x 4.5 inch	2	001.736292 001.736322 001.736326 001.736330 001.749526
Platter coup M5379 44 x 14 cm / 17.3 x 5.6 inch	2	001.736291 001.736321 001.736325 001.736329 001.749527
Selplatter 44 cm / 17.5 x 5.6 inch	2	001.736294 001.736324 001.736328 001.736332 001.749528
Bowl high 0,18 ltr. / 6.3 oz.	6	001.736289 001.736318 001.736349 001.736378 001.749529
Bowl low 0,21 ltr. / 6.8 oz.	6	001.736287 001.736317 001.736347 001.736377 001.749530



¹ PU = Packing Unit

ITEM DESCRIPTION	PU ¹	Item-No
Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.736295 001.736325 001.736329 001.736333 001.749531
Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.736296 001.736326 001.736330 001.736334 001.749532
Creamer 2 0,23 ltr. / 7.7 oz.	1	001.736297 001.736327 001.736331 001.736335 001.749533
Mocha cup 1132 0,09 ltr. / 3.0 oz.	6	001.736299 001.736329 001.736333 001.736337 001.749535
Saucer 1132 12 cm / 4.7 inch	6	001.736298 001.736328 001.736332 001.736336 001.749534
Cup 1163 0,18 ltr. / 6.0 oz.	6	001.736304 001.736334 001.736338 001.736342 001.749536
Saucer 1163 14,7 cm / 5.8 inch	6	001.736303 001.736333 001.736337 001.736341 001.749537
Cappuccino cup 1131 0,22 ltr. / 7.3 oz.	6	001.736302 001.736332 001.736336 001.736340 001.749538
Saucer 1131 14,7 cm / 5.8 inch	6	001.736301 001.736331 001.736335 001.736339 001.749539
Cup 1164 0,37 ltr. / 12.3 oz.	6	001.736306 001.736336 001.736340 001.736344 001.749540
Saucer 1164 16 cm / 6.3 inch	6	001.736305 001.736335 001.736339 001.736343 001.749541
Cup 5041 without handle 0,50 ltr. / 16.7 oz.	6	001.736307 001.736337 001.736341 001.736345 001.749542
Mug with handle 5005 0,25 ltr. / 8.3 oz. non stackable	6	001.736309 001.736339 001.736343 001.736347 001.749543
Mug with handle 5025 0,40 ltr. / 13.3 oz. non stackable	6	001.736308 001.736338 001.736342 001.736346 001.749544



BUFFET GOURMET

»FANTASTIC«

ITEM DESCRIPTION	PU ¹	Item-No	ITEM DESCRIPTION	PU ¹	Item-No
Bowl 5140 15 x 15 cm / 6.0 x 6.0 inch	2	001.736096 ² 001.736128 ³ 001.736150 ⁴ 001.736182 ⁵ 001.749479 ⁶	Dressing pot without lid 5140 1,00 ltr. / 33.3 oz.	1	001.736100 ² 001.736132 ³ 001.736162 ⁴ 001.736192 ⁵ 001.749482 ⁶
Bowl 5140 20 x 20 cm / 8.0 x 8.0 inch	1	001.736097 ² 001.736129 ³ 001.736151 ⁴ 001.736183 ⁵ 001.749477 ⁶	Platter 5170 16 x 16 cm / 6.3 x 6.3 inch	2	001.736101 ² 001.736133 ³ 001.736163 ⁴ 001.736193 ⁵ 001.749483 ⁶
Bowl 5140 26 x 26 cm / 10.3 x 10.3 inch	1	001.736098 ² 001.736130 ³ 001.736152 ⁴ 001.736184 ⁵ 001.749478 ⁶	Platter 5170 23 x 23 cm / 9.0 x 9.0 inch	1	001.736102 ² 001.736134 ³ 001.736164 ⁴ 001.736194 ⁵ 001.749484 ⁶
Bowl 5180 25 x 25 x 7 cm / 9.9 x 9.9 inch	1	001.737880 ² 001.737881 ³ 001.737882 ⁴ 001.737883 ⁵ 001.749479 ⁶	Platter 5170 32,5 x 22,4 cm / 12.8 x 4.3 inch	1	001.736103 ² 001.736135 ³ 001.736165 ⁴ 001.736195 ⁵ 001.749485 ⁶
Bowl 5180 35 x 35 x 5 cm / 13.8 x 13.8 inch	1	001.737884 ² 001.737885 ³ 001.737886 ⁴ 001.737887 ⁵ 001.749480 ⁶	Platter 5170 32,5 x 10,8 cm / 12.8 x 8.8 inch	1	001.736104 ² 001.736136 ³ 001.736166 ⁴ 001.736196 ⁵ 001.749486 ⁶
Dressing pot without lid 5140 1,50 ltr. / 50.0 oz.	1	001.736099 ² 001.736131 ³ 001.736153 ⁴ 001.736185 ⁵ 001.749481 ⁶	Platter 5170 32,5 x 32,5 cm / 12.8 x 12.8 inch	1	001.736105 ² 001.736137 ³ 001.736167 ⁴ 001.736197 ⁵ 001.749487 ⁶


¹ PU = Packing Unit

² 6th: cooling tray stainless steel 7 inch

BUFFET GOURMET

»FANTASTIC«

ITEM DESCRIPTION	PU ¹	Item-No	ITEM DESCRIPTION	PU ¹	Item-No
GN Platter 5170-1/1 53 x 32,5 cm / 20.8 x 12.8 inch	1	001.736106 ² 001.736138 ³ 001.736168 ⁴ 001.736198 ⁵ 001.749488 ⁶	Bowl with cover 5120 3,50 ltr. / 150.0 oz.	1	001.736120 ² 001.736152 ³ 001.736182 ⁴ 001.736212 ⁵ 001.749502 ⁶
GN Platter 5170-1/2 32,5 x 26,5 cm / 12.8 x 10.4 inch	2	001.736107 ² 001.736139 ³ 001.736169 ⁴ 001.736199 ⁵ 001.749489 ⁶	Bowl without cover 5120 3,50 ltr. / 150.0 oz.	1	001.736121 ² 001.736153 ³ 001.736183 ⁴ 001.736213 ⁵ 001.749503 ⁶
GN Platter 5170-1/3 32,5 x 17,6 cm / 12.8 x 7.0 inch	3	001.736108 ² 001.736140 ³ 001.736170 ⁴ 001.736200 ⁵ 001.749490 ⁶	Cover for bowl 5120 17 cm / 6.7 inch	1	001.736122 ² 001.736154 ³ 001.736184 ⁴ 001.736214 ⁵ 001.749504 ⁶
GN Platter 5170-2/4 53 x 16,2 cm / 20.8 x 6.4 inch	2	001.736109 ² 001.736141 ³ 001.736171 ⁴ 001.736201 ⁵ 001.749491 ⁶	Bowl with cover 5140 2,00 ltr. / 66.6 oz.	1	001.736123 ² 001.736155 ³ 001.736185 ⁴ 001.736215 ⁵ 001.749505 ⁶
Platter round 5120 18 cm / 9.0 inch*	1	001.736110 ² 001.736142 ³ 001.736172 ⁴ 001.736202 ⁵ 001.749492 ⁶	Bowl without cover 5140 2,00 ltr. / 66.6 oz.	1	001.736124 ² 001.736156 ³ 001.736186 ⁴ 001.736216 ⁵ 001.749506 ⁶
Bowl 5140 6 x 6 cm / 2.3 x 2.3 inch	6	001.736111 ² 001.736143 ³ 001.736173 ⁴ 001.736203 ⁵ 001.749493 ⁶	Cover for bowl 5140 19,5 cm / 7.7 inch	1	001.736125 ² 001.736157 ³ 001.736187 ⁴ 001.736217 ⁵ 001.749507 ⁶
Bowl 5140 10 x 10 cm / 3.9 x 3.9 inch	2	001.736112 ² 001.736144 ³ 001.736174 ⁴ 001.736204 ⁵ 001.749494 ⁶	Bowl sloping 8,5 cm / 3.4 inch (SAVOY)	6	001.736080 ² 001.736084 ³ 001.736088 ⁴ 001.736092 ⁵ 001.749508 ⁶
Bowl 5120 - 28/11 28 cm / 11.0 inch	1	001.736113 ² 001.736145 ³ 001.736175 ⁴ 001.736205 ⁵ 001.749495 ⁶	Bowl sloping 11 cm / 4.4 inch (SAVOY)	6	001.736083 ² 001.736087 ³ 001.736091 ⁴ 001.736095 ⁵ 001.749509 ⁶
Bowl with cover 5120 0,50 ltr. / 23.3 oz.	1	001.736114 ² 001.736146 ³ 001.736176 ⁴ 001.736206 ⁵ 001.749496 ⁶	Bowl square 9 cm / 3.5 x 3.5 inch (SAVOY)	6	001.736081 ² 001.736085 ³ 001.736089 ⁴ 001.736093 ⁵ 001.749510 ⁶
Bowl without cover 5120 0,50 ltr. / 23.3 oz.	1	001.736115 ² 001.736147 ³ 001.736177 ⁴ 001.736207 ⁵ 001.749497 ⁶	Bowl square 11 cm / 4.8 x 4.8 inch (SAVOY)	6	001.736082 ² 001.736086 ³ 001.736090 ⁴ 001.736094 ⁵ 001.749511 ⁶
Cover for bowl 5120 8 cm / 3.3 inch	1	001.736116 ² 001.736148 ³ 001.736178 ⁴ 001.736208 ⁵ 001.749498 ⁶			
Bowl with cover 5120 1,50 ltr. / 63.3 oz.	1	001.736117 ² 001.736149 ³ 001.736179 ⁴ 001.736209 ⁵ 001.749499 ⁶			
Bowl without cover 5120 1,50 ltr. / 63.3 oz.	1	001.736118 ² 001.736150 ³ 001.736180 ⁴ 001.736210 ⁵ 001.749500 ⁶			
Cover for bowl 5120 11 cm / 4.3 inch	1	001.736119 ² 001.736151 ³ 001.736181 ⁴ 001.736211 ⁵ 001.749501 ⁶			



- 2 »royal blue« 57122
- 3 »turquoise« 57123
- 4 »grey« 57124
- 5 »caramel« 57125
- 6 »brick red« 57126



C


COUP FINE DINING

»COUNTRY LIFE«

ITEM DESCRIPTION	PU*	Item-No
Showplate flat M5380 33 cm / 13.1 inch	4	001.731546P 001.731550P
Plate flat coup M5380 30 cm / 12.0 inch	6	001.731540P 001.731554P
Plate flat coup M5380 28 cm / 11.1 inch	6	001.731536P 001.731553P
Plate flat coup M5380 26 cm / 10.3 inch	6	001.731538P 001.731552P
Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.731537P 001.731551P
Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.731536P 001.731550P
Bowl coup M5381 28 cm / 11.0 inch	4	001.731545P 001.731556P
Bowl coup M5381 26 cm / 10.3 inch	6	001.731544P 001.731555P
Bowl coup M5381 23 cm / 9.2 inch	6	001.731543P 001.731554P
Bowl coup M5381 20 cm / 7.9 inch	6	001.731542P 001.731553P
Bowl coup M5381 14,5 cm / 5.7 inch	6	001.731541P 001.731552P
Platter coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.733793P 001.733790P
Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.731547P 001.731561P
Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.731548P 001.731562P
Platter coup M5379 35 x 11 cm / 13.9 x 4.5 inch	2	001.733792P 001.733794P
Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.731549P 001.731563P
Setplatter 44 cm / 17.5 x 5.6 inch	2	001.732812P 001.732815P
Bowl high 0,18 ltr. / 6.3 oz.	6	001.732811P 001.732814P
Bowl low 0,21 ltr. / 6.7 oz.	6	001.732810P 001.732813P

* PU = Packing Unit

ITEM DESCRIPTION	PU*	Item-No
Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.731968P 001.731991P
Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.731969P 001.731992P
Creamer 2 0,23 ltr. / 7.7 oz.	1	001.731970P 001.731993P
Mocha cup 1132 0,09 ltr. / 3.0 oz.	6	001.731972P 001.731995P
Saucer 1132 12 cm / 4.7 inch	6	001.731971P 001.731994P
Cup 1163 0,18 ltr. / 6.0 oz.	6	001.731977P 001.732001P
Saucer 1163 14,7 cm / 5.8 inch	6	001.731976P 001.731999P
Cappuccino cup 1131 0,22 ltr. / 7.3 oz.	6	001.731975P 001.731998P
Saucer 1131 14,7 cm / 5.8 inch	6	001.731974P 001.731997P
Cup 1164 0,37 ltr. / 12.3 oz.	6	001.731979P 001.732003P
Saucer 1164 16 cm / 6.3 inch	6	001.731978P 001.732002P
Cup without handle 5041 0,50 ltr. / 16.7 oz.	6	001.731973P 001.731996P
Mug with handle non stackable 5005 0,25 ltr. / 8.3 oz.	6	001.731989P 001.732004P
Mug with handle non stackable 5025 0,40 ltr. / 13.3 oz.	6	001.731990P 001.732005P



[2] »champagne« 57010

[3] »petrol« 57011




C

COUP FINE DINING

»COUNTRY LIFE«

ITEM DESCRIPTION	PU ¹	Item-No
Showplate flat M5380 33 cm / 13.1 inch	4	001.731574 ^a 001.731580 ^a
Plate flat coup M5380 30 cm / 12.0 inch	6	001.731568 ^a 001.731582 ^a
Plate flat coup M5380 28 cm / 11.1 inch	6	001.731567 ^a 001.731581 ^a
Plate flat coup M5380 26 cm / 10.3 inch	6	001.731566 ^a 001.731580 ^a
Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.731565 ^a 001.731579 ^a
Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.731564 ^a 001.731578 ^a
Bowl coup M5381 28 cm / 11.0 inch	4	001.731573 ^a 001.731587 ^a
Bowl coup M5381 26 cm / 10.3 inch	6	001.731572 ^a 001.731586 ^a
Bowl coup M5381 23 cm / 9.2 inch	6	001.731571 ^a 001.731585 ^a
Bowl coup M5381 20 cm / 7.9 inch	6	001.731570 ^a 001.731584 ^a
Bowl coup M5381 14,5 cm / 5.7 inch	6	001.731569 ^a 001.731583 ^a
Platter coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.733797 ^a 001.733799 ^a
Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.731575 ^a 001.731589 ^a
Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.731576 ^a 001.731590 ^a
Platter coup M5379 35 x 11 cm / 13.9 x 4.5 inch	2	001.733796 ^a 001.733798 ^a
Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.731577 ^a 001.731591 ^a
Selplatter 44 cm / 17.5 x 5.6 inch	2	001.732618 ^a 001.732621 ^a
Bowl high 0,18 ltr. / 6.3 oz.	6	001.732617 ^a 001.732620 ^a
Bowl low 0,21 ltr. / 6.7 oz.	6	001.732616 ^a 001.732619 ^a

ITEM DESCRIPTION	PU ¹	Item-No
Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.732009 ^a 001.732020 ^a
Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.732007 ^a 001.732021 ^a
Creamer 2 0,23 ltr. / 7.7 oz.	1	001.732008 ^a 001.732022 ^a
Mocha cup 1132 0,09 ltr. / 3.0 oz.	6	001.732010 ^a 001.732024 ^a
Saucer 1132 12 cm / 4.7 inch	6	001.732009 ^a 001.732023 ^a
Cup 1163 0,18 ltr. / 6.0 oz.	6	001.732015 ^a 001.732029 ^a
Saucer 1163 14,7 cm / 5.8 inch	6	001.732014 ^a 001.732028 ^a
Cappuccino cup 1131 0,22 ltr. / 7.3 oz.	6	001.732013 ^a 001.732027 ^a
Saucer 1131 14,7 cm / 5.8 inch	6	001.732012 ^a 001.732026 ^a
Cup 1164 0,37 ltr. / 12.3 oz.	6	001.732017 ^a 001.732031 ^a
Saucer 1164 16 cm / 6.3 inch	6	001.732016 ^a 001.732030 ^a
Cup without handle 5041 0,50 ltr. / 16.7 oz.	6	001.732011 ^a 001.732025 ^a
Mug with handle non stackable 5005 0,25 ltr. / 8.3 oz.	6	001.732018 ^a 001.732032 ^a
Mug with handle non stackable 5025 0,40 ltr. / 13.3 oz.	6	001.732019 ^a 001.732033 ^a



¹ PU = Packing Unit



2 »Reflections« 57514
3 »Growth« 57516

C

COUP FINE DINING

»REFLECTIONS« | »GROWTH«

ITEM DESCRIPTION	PU ¹	Item-No
Showplate flat M5380 33 cm / 13.1 inch	4	001.749609 ² 001.749585 ³
Plate flat coup M5380 30 cm / 12.0 inch	6	001.749607 ² 001.749589 ³
Plate flat coup M5380 28 cm / 11.1 inch	6	001.749609 ² 001.749587 ³
Plate flat coup M5380 26 cm / 10.3 inch	6	001.749609 ² 001.749589 ³
Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.749610 ² 001.749589 ³
Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.749611 ² 001.749590 ³
Bowl coup M5381 28 cm / 11.0 inch	4	001.749612 ² 001.749591 ³
Bowl coup M5381 26 cm / 10.3 inch	6	001.749613 ² 001.749592 ³
Bowl coup M5381 23 cm / 9.2 inch	6	001.749614 ² 001.749593 ³



¹ PU = Packing Unit

ITEM DESCRIPTION	PU ¹	Item-No
Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.749615 ² 001.749594 ³
Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.749616 ² 001.749595 ³
Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.749617 ² 001.749596 ³
Plate flat coup square M5383 29 x 29 cm / 11.5 x 11.5 inch	4	001.749618 ² 001.749597 ³
Plate flat coup square M5383 26 x 26 cm / 10.3 x 10.3 inch	6	001.749619 ² 001.749598 ³
Plate flat coup square M5383 22 x 22 cm / 8.6 x 8.6 inch	6	001.749620 ² 001.749599 ³
Plate flat coup square M5383 16,5 x 16,5 cm / 6.5 x 6.5 inch	6	001.749621 ² 001.749600 ³
Bowl coup square M5384 26 x 26 cm / 10.0 x 10.0 inch	4	001.749622 ² 001.749601 ³
Bowl coup square M5384 22 x 22 cm / 8.6 x 8.6 inch	6	001.749623 ² 001.749602 ³
Plate flat coup rectangular 35 x 20 cm / M5385 14.0 x 8.0 inch	2	001.749624 ² 001.749603 ³
Bowl coup rectangular M5386 25,5 x 18 cm / 10.0 x 7.0 inch	2	001.749625 ² 001.749604 ³
Platter coup rectangular M5388 38 x 14 cm / 15.0 x 6.6 inch	2	001.749626 ² 001.749605 ³





C

COUP FINE DINING

»BLUE SEA« 57515

ITEM DESCRIPTION	PU ¹	Item-No
Showplate flat M5360 33 cm / 13.1 inch	4	001.749686
Plate flat coup M5360 30 cm / 12.0 inch	6	001.749687
Plate flat coup M5360 28 cm / 11.1 inch	6	001.749688
Plate flat coup M5360 26 cm / 10.3 inch	6	001.749689
Plate flat coup M5360 21,5 cm / 8.5 inch	6	001.749690
Plate flat coup M5360 16,5 cm / 6.5 inch	6	001.749691
Bowl coup M5381 28 cm / 11.0 inch	4	001.749692
Bowl coup M5381 26 cm / 10.3 inch	6	001.749693
Bowl coup M5381 23 cm / 9.2 inch	6	001.749694

ITEM DESCRIPTION	PU ¹	Item-No
Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.749695
Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.749696
Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.749697
Plate flat coup square M5383 29 x 29 cm / 11.5 x 11.5 inch	4	001.749700
Plate flat coup square M5383 26 x 26 cm / 10.3 x 10.3 inch	6	001.749702
Plate flat coup square M5383 22 x 22 cm / 8.6 x 8.6 inch	6	001.749703
Plate flat coup square M5383 16,5 x 16,5 cm / 6.5 x 6.5 inch	6	001.749705
Bowl coup square M5384 26 x 26 cm / 10.0 x 10.0 inch	4	001.749706
Bowl coup square M5384 22 x 22 cm / 8.6 x 8.6 inch	6	001.749708
Plate flat coup rectangular 35 x 20 cm / M5385 14.0 x 8.0 inch	2	001.949709
Bowl coup rectangular M5386 25,5 x 18 cm / 10.0 x 7.0 inch	2	001.749710
Platter coup rectangular M5388 38 x 14 cm / 15.0 x 6.6 inch	2	001.749711



¹ PU = Packing Unit



MERAN

»SPRINGCOLORS«

ITEM DESCRIPTION	PU*
Coffee pot 1 0,36 ltr. / 12.0 oz.	2
Tea pot 1 0,32 ltr. / 10.7 oz.	2
Sugar bowl 2 0,23 ltr. / 7.7 oz.	1
Sugar bowl 1164 0,37 ltr. / 12.3 oz.	6
Sugar dish 8,2 cm / 3.2 inch	12
Creamer 00 0,02 ltr. / 0.7 oz.	12
Creamer 1 0,15 ltr. / 5.0 oz.	1
Creamer 2 0,23 ltr. / 7.7 oz.	1
Espresso cup 5241 0,09 ltr. / 3.0 oz.	6
Saucer 5241 12,7 cm / 5.0 inch	6
Coffee cup 5242 0,20 ltr. / 6.7 oz.	6
Saucer 5242/5243 16,2 cm / 6.4 inch	6
Mug with handle DVA 5156 0,35 ltr. / 13.3 oz.	6
Saucer 5156 17,5 cm / 6.9 inch	6
Saucer oval 19 cm / 7.4 x 5.0 inch	6
Saucer oval 21,5 cm / 8.5 x 6.0 inch	6
Plate flat 33 cm / 13.0 inch	6
Plate flat 30 cm / 12.0 inch	6
Plate flat 28 cm / 11.0 inch	6
Plate flat 26 cm / 10.2 inch	6
Plate flat 23 cm / 9.0 inch	6
Plate flat 20 cm / 8.0 inch	6
Plate flat 17 cm / 6.8 inch	6
Plate deep 23 cm / 8.9 inch	6
Bowl 1060 0,60 ltr. / 20.0 oz.	6

ITEM DESCRIPTION	PU*
Coup plate flat oval 5234 21 cm / 8.3 x 7.6 inch	6
Coup plate flat oval 5195 25 cm / 9.8 x 9.0 inch	6
Coup plate flat oval 5193 27 cm / 10.6 x 9.7 inch	6
Coup plate flat oval 5192 29 cm / 11.5 x 11.0 inch	6
Coup plate flat oval 5235 34 cm / 13.4 x 12.0 inch	2
Coup plate flat round 5196 15,5 cm / 6.2 inch	6
Coup plate flat round 5197 17,5 cm / 7.0 inch	6
Coup plate flat round 5206 21,5 cm / 8.5 inch	6
Coup plate flat round 5209 25,5 cm / 10.0 inch	6
Coup plate flat round 5210 29 cm / 11.5 inch	6
Coup plate deep 5236 14,5 cm / 5.7 inch	6
Coup plate deep 5237 23 cm / 9.0 inch	6
Coup plate deep 5211 29 cm / 11.6 inch	6
Soup bowl oval 5238 16 cm / 6.0 x 5.3 inch	4
Bowl oval 5239 21 cm / 8.3 x 7.0 inch	2
Bowl oval 5240 25,5 cm / 10.0 x 8.5 inch	2
Bowl round 15 cm / 5.8 inch	4
Bowl round 20 cm / 7.8 inch	2
Bowl round 23 cm / 9.0 inch	2
Oval plate flat 25 cm / 9.8 x 6.4 inch	2
Oval plate flat 28 cm / 11.0 x 8.3 inch	2
Oval plate flat 31 cm / 12.3 x 9.0 inch	2
Oval plate flat 35 cm / 13.8 x 10.4 inch	2
Set salt and pepper	1
Coffee cup 1 0,10 ltr. / 6.0 oz. stackable	6
Saucer 1 16,2 cm / 6.4 inch	6



* PU = Packing Unit



1 »Brasile» 23298 2 »Bolivi» 23299 3 »Costa Rica» 23300
4 »Kenia» 23301 5 »Vietnam» 23302 6 »Guatemala» 23303

Décor 23298 - 23303

ITEM DESCRIPTION	PU*
Espresso cup 1132 0,09 ltr. / 3.0 oz.	6
Saucer 1132 12 cm / 4.7 inch	6
Cappuccino cup 1131 0,23 ltr. / 7.3 oz.	6
Saucer 1131 14,5 cm / 5.8 inch	6
Milkcoffee cup 1164 0,37 ltr. / 12.3 oz.	6
Saucer 1164 16 cm / 6.3 inch	6
Mug 5005 0,25 ltr. / 8.3 oz.	1
Mug 5025 0,40 ltr. / 13.3 oz.	1
Bowl 5121 13 cm / 5.1 inch	1
Plate flat round 20 cm / 7.9 inch LUKULLUS 23304	6

Décor 10324 - 10328

ITEM DESCRIPTION	PU*
Espresso cup 1132 0,09 ltr. / 3.0 oz.	6
Saucer 1132 12 cm / 4.7 inch	6
Jumbo cup 5041 0,50 ltr. / 16.7 oz.	1
Saucer 5041 19 cm / 7.5 inch	6
Cappuccino cup 1131 0,23 ltr. / 7.3 oz.	6
Saucer 1131 14,5 cm / 5.8 inch	6
Milkcoffee cup 1164 0,37 ltr. / 12.3 oz.	6
Saucer 1164 16 cm / 6.3 inch	6
Mug 5042 0,50 ltr. / 16.7 inch	1
Mug 5005 0,25 ltr. / 8.3 oz.	1
Mug 5025 0,40 ltr. / 13.3 oz.	1
Plate flat round 20 cm / 7.9 inch*	6

Décor 22124 - 22129

ITEM DESCRIPTION	PU*
Espresso cup 1132 0,09 ltr. / 3.0 oz.	6
Saucer 1132 12 cm / 4.7 inch	6
Cappuccino cup 1131 0,23 ltr. / 7.3 oz.	6
Saucer 1131 14,5 cm / 5.8 inch	6
Milkcoffee cup 1164 0,37 ltr. / 12.3 oz.	6
Saucer 1164 16 cm / 6.3 inch	6
Mug 5005 0,25 ltr. / 8.3 oz.	1
Mug 5025 0,40 ltr. / 13.3 oz.	1
Plate flat round 20 cm / 7.9 inch LUKULLUS 22130	6



1 »red» 10324 2 »blue» 10325
3 »yellow» 10326 4 »green» 10327
5 »orange» 10328



1 »Massa» 22124 2 »Loreto» 22125 3 »Termoli» 22126
4 »Rapallo» 22127 5 »Grado» 22128 6 »Imperia» 22129



* PU = Packing Unit
* Available in all colors.



BUFFET PLUS

DISCONTINUED AFTER 03/2020

ITEM DESCRIPTION	PU ¹	Item-No ²
Bowl triangle 5290 11 cm / 4.3 inch	4	001.697893
Bowl triangle 5290 20 cm / 7.8 inch	2	001.697894
Bowl triangle 5290 26 cm / 10.0 inch	2	001.697895
Bowl triangle 5290 31 cm / 12.5 inch	2	001.697896
Bowl triangle 5290 38 cm / 15.1 inch	2	001.697897
Bowl triangle high 5294 31 cm / 12.3 inch	2	001.697892
Bowl triangle 5291 9.5 cm / 3.8 inch	4	001.697900
Bowl triangle 5291 15 cm / 5.8 inch	2	001.697901
Bowl triangle 5291 19 cm / 7.9 inch	2	001.697902
Bowl triangle 5291 23 cm / 9.1 inch	2	001.697903
Bowl triangle 5291 28 cm / 11.0 inch	2	001.697904
Bowl triangle 5291 38 cm / 15.0 inch	1	001.697905

ITEM DESCRIPTION	PU ¹	Item-No ²
Bowl triangle high 5293 11 cm / 4.3 inch	2	001.697906
Dressing pot triangle 5252 1,00 ltr. / 33.3 oz.	1	001.697898
Dressing pot triangle 5252 1,85 ltr. / 61.7 oz.	1	001.697899



¹ PU = Packing Unit
² Item-No refers to undecorated articles



BUFFET GOURMET

ITEM DESCRIPTION	PU ¹	Item-No ²
Platter rect. 5140 18 x 16 cm / 8.2 x 6.2 inch	2	001.590330
Platter rect. 5140 25 x 25 cm / 10.0 x 10.0 inch	2	001.590405
Platter rect. 5140 25 x 14 cm / 10.0 x 5.6 inch	2	001.591293
Platter rect. 5140 35 x 14 cm / 14.0 x 5.6 inch	1	001.590505
Platter rect. 5140 35 x 25 cm / 14.0 x 10.0 inch	1	001.590530
Platter rect. 5140 35 x 35 cm / 14.0 x 14.0 inch	1	001.590580
Bowl 5140 11 x 11 cm / 4.3 x 4.3 inch	4	001.588734
Bowl 5140 15 x 15 cm / 6.0 x 6.0 inch	2	001.590205
Bowl 5140 17 x 17 cm / 6.6 x 6.6 inch	2	001.588759
Bowl 5140 20 x 20 cm / 8.0 x 8.0 inch	1	001.590255
Bowl 5140 23 x 23 cm / 9.0 x 9.0 inch	1	001.590830
Bowl 5140 29 x 29 cm / 10.2 x 10.2 inch	1	001.590955
Bowl 5140 6 x 6 cm / 2.4 x 2.4 inch	6	001.591508
Bowl 5140 10 x 10 cm / 4.0 x 4.0 inch	2	001.590980
Bowl 5140 10 x 20 cm / 8.0 x 4.0 inch	2	001.591583
Bowl 5140 5 x 20 cm / 8.0 x 2.0 inch	1	001.590105
Bowl 5140 5 x 30 cm / 12.0 x 2.0 inch	1	001.590155
Dressing pot 5140 1,50 ltr. / 50.0 oz.	1	001.589924
Dressing pot 5140 1,00 ltr. / 33.3 oz.	1	001.591458
Dressing pot 5140	12	001.591483



¹ PU = Packing Unit
² Item-No refers to undecorated articles

ITEM DESCRIPTION	PU ¹	Item-No ²
Bowl 5160 25 x 25 x 7 cm / 10.0 x 10.0 inch	2	001.589543
Bowl 5160 20 x 20 x 7 cm / 8.0 x 8.0 inch	2	001.589493
Bowl 5160 16 x 16 x 7 cm / 6.2 x 6.2 inch	1	001.589480
Bowl 5160 10 x 20 x 7 cm / 8.0 x 4.0 inch	1	001.589443
Bowl 5160 10 x 10 x 7 cm / 4.0 x 4.0 inch	1	001.737676
Platter rect. 5170 10 x 10 cm / 4.0 x 4.0 inch	2	001.589593
Platter rect. 5170 10 x 20 cm / 8.0 x 4.0 inch	2	001.589646
Platter rect. 5170 16 x 16 cm / 6.2 x 6.2 inch	2	001.589771
Platter rect. 5170 20 x 20 cm / 8.0 x 8.0 inch	2	001.589696
Platter rect. 5170 23 x 23 cm / 9.0 x 9.0 inch	1	001.589426
Platter rect. 5170 32,5 x 10,8 cm / 12,7 x 4,2 inch	1	001.589427
Platter rect. 5170 32,5 x 22,4 cm / 12,7 x 8,8 inch	1	001.589428
Platter rect. 5170 32,5 x 32,5 cm / 12,7 x 12,7 inch	1	001.589429
GN-Platter 5170-1/1 53 x 32,5 cm / 20,8 x 12,7 inch	1	001.700036
GN-Platter 5170-1/2 32,5 x 26,5 cm / 12,7 x 10,4 inch	2	001.700037
GN-Platter 5170-1/3 32,5 x 17,6 cm / 12,7 x 7,0 inch	3	001.700038
GN-Platter 5170-2/4 53 x 16,2 cm / 20,8 x 6,3 inch	2	001.700039
Bowl 5180 10 x 10 x 5 cm / 4.0 x 4.0 inch	4	001.590002
Bowl 5180 16 x 16 x 5 cm / 6.2 x 6.2 inch	1	001.589949
Bowl 5180 35 x 35 x 5 cm / 14.0 x 14.0 inch	1	001.737677





BUFFET GOURMET

ITEM DESCRIPTION	PU ¹	Item-No ²
Bowl 5120-18/9 18 cm / 7.0 inch	4	001.632250
Bowl 5120-24/11 24 cm / 9.4 inch	2	001.632251
Bowl 5120-28/11 28 cm / 11.0 inch	1	001.590305
Bowl 5120-30/15 30 cm / 12.0 inch	1	001.590280
Bowl with lid 5120 0,50 ltr. / 23.3 oz.	1	001.650976
Bowl with lid 5120 1,50 ltr. / 63.3 oz.	1	001.650985
Bowl with lid 5120 3,50 ltr. / 150.0 oz.	1	001.650994
Bowl with lid 5140 2,00 ltr. / 66.7 oz.	1	001.630852
Bowl without lid 5140 2,00 ltr. / 66.7 oz.	1	001.588934
Baker oval 22 x 14,5 cm / 8.7 x 5.7 inch (LUKULLUS)	1	001.103257
Roaster rectangular (LUKULLUS) 30 x 18,5 cm / 12.0 x 7.3 inch	1	001.103733
Roaster rectangular (LUKULLUS) 35 x 21,5 cm / 13.7 x 8.5 inch	1	001.103969
Roaster rectangular (LUKULLUS) 38 x 24 cm / 15.0 x 9.4 inch	1	001.104127
Souffle oval (LUKULLUS) 24 x 15 cm / 9.6 x 6.0 inch	1	001.104901
Flan dish round (LUKULLUS) 18 cm / 7.2 inch	1	001.484117
Toothpickholder 5140 5 x 4,5 cm / 1.7 inch	2	001.530946
Creamer 5140	6	001.588541
Sugarstickholder 5140	6	001.588491

¹ PU = Packing Unit
² Item-No refers to undecorated articles

GASTRONORMUNIT

ITEM DESCRIPTION	PU ¹	Item-No ²
GN-Unit 1/1 1402/121	1	001.591796
GN-Unit 1/2 1402/122	1	001.591836
GN-Unit 1/3 1402/123	1	001.591911
GN-Unit 1/4 1402/124	1	001.591961
GN-Unit 2/4 1402/224	1	001.592011
GN-Unit 1/3 1402/143	1	001.592181
GN-Unit 1/4 1402/144	1	001.592186
GN-Unit 2/4 1402/244	1	001.592061
GN-Unit 1/1 1402/101	1	001.591636
GN-Unit 1/2 1402/102	1	001.591661
GN-Unit 2/3 1402/203	1	001.591686
GN-Unit 1/3 1402/103	1	001.591711
GN-Unit 1/4 1402/104	1	001.591736
GN-Unit 2/4 1402/204	1	001.591701
GN-Unit 1/6 1402/106	1	001.592311





MUG TO GO

ITEM DESCRIPTION	PU ¹	Item-No ²
 Mug To Go 0,42 ltr. / 14.0 oz.	6	001.751057
 Lid to go	6	001.751058
 Sleeve to go	6	001.751059
 Mug To Go 0,42 ltr. / 14.0 oz.	1	001.751056

¹ PU = Packing Unit
² Item-No refers to undecorated articles





C COMMUNITY

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 20 cm / 8.0 inch	6	001.743398
Plate flat with rim 23 cm / 9.0 inch	6	001.743399
Plate flat 25,5 cm / 10.0 inch	6	001.743400
Soup plate with rim 25,5 cm / 10.0 inch	6	001.743410
Plate deep 23 cm / 9.0 inch	6	001.743403
Salad plate 12 cm / 4.6 inch	4	001.743405
Salad plate 13,5 cm / 5.4 inch	4	001.743406
Coffee cup 0,18 ltr. / 6.0 oz.	6	001.743430
Coffee cup non stackable 0,22 ltr. / 7.3 oz.	6	001.743431
Saucer 1 15,5 cm / 6.0 inch	6	001.743432
Mug with handle 0,28 ltr. / 9.3 oz.	6	001.743433
Mug with two handles 0,28 ltr. / 9.3 oz.	6	001.743434
Soup cup 0,30 ltr. / 11.7 oz.	6	001.743404
Saucer 1 15,5 cm / 6.0 inch	6	001.743432
Coffee pot 1 0,38 ltr. / 12.7 oz.	2	001.743417
Tea pot 1 0,55 ltr. / 18.3 oz.	2	001.743420
Warming plate 1069 small	1	001.743435
Sugar bowl 2 0,28 ltr. / 9.3 oz.	1	001.743423
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.743426
Creamer 2 0,25 ltr. / 8.3 oz.	1	001.743427
Mocha cup 0,09 ltr. / 3.0 oz.	6	001.743429
Saucer 13,5 cm / 5.4 inch	6	001.743428

¹ PU = Packing Unit
² Item-No refers to undecorated articles

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat 30 cm / 12.0 inch	6	001.743402
Plate flat 28 cm / 11.3 inch	6	001.743401
Plate flat 17 cm / 6.7 inch	6	001.743397
Salad plate 19 cm / 7.5 inch	6	001.743411
Pasta plate deep 27 cm / 10.7 inch	2	001.743412
Gravy boat 0,45 ltr. / 15.7 oz.	2	001.743413
Bowl round 18 cm / 7.0 inch	2	001.743407
Bowl round 21 cm / 8.3 inch	2	001.743408
Bowl round 24 cm / 9.5 inch	2	001.743409
Oval platter 31 cm / 12.3 x 9.4 inch	2	001.743415
Oval platter 35 cm / 13.8 x 11.0 inch	2	001.743416
Vase	1	001.743436
Candleholder	1	001.743437
Egg cup with rest	6	001.743414





The saucers are moulded deep so that cups and mugs remain standing safely in the hollow of the saucer, even if tipped to an extreme angle.



The mug handles are designed to be big and easy to grasp. Additional protection prevents users from burning their fingers.



IMPERIAL

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,35 ltr. / 11.8 oz.	2	001.560532
Tea pot 1 0,35 ltr. / 11.8 oz.	2	001.562645
Sugar bowl 2 0,20 ltr. / 6.7 oz.	1	001.564493
Creamer 4 0,15 ltr. / 5.0 oz.	1	001.565946
Creamer 5 0,30 ltr. / 10.0 oz.	1	001.566735
Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.570565
Saucer 1 16 cm / 6.3 inch	6	001.569905
Coffee cup 2 0,16 ltr. / 5.3 oz.	6	001.572016
Saucer 13,6 cm / 5.3 inch	12	001.568847
Milkcoffee cup 0,22 ltr. / 7.3 oz.	6	001.573468
Saucer 1 15,1 cm / 5.9 inch	6	001.569905
Egg cup with rest	6	001.555912
Plate flat with rim 30 cm / 12.0 inch	6	001.547201
Plate flat with rim 27 cm / 10.7 inch	6	001.546541
Plate flat with rim 25 cm / 10.0 inch	6	001.545881
Plate flat with rim 21 cm / 8.3 inch	6	001.545221
Plate flat with rim 19 cm / 7.5 inch	6	001.544662
Plate flat with rim 17 cm / 6.8 inch	6	001.544164
Plate flat with rim 15 cm / 6.0 inch	6	001.543767
Soup plate deep 23 cm / 9.0 inch	6	001.547360
Salad plate deep 19 cm / 7.5 inch	6	001.553404
Soup cup 0,30 ltr. / 10.0 oz.	6	001.549443
Saucer 1 15,1 cm / 5.9 inch	6	001.569905
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.554724
Bowl round 13 cm / 5.3 inch	4	001.549972
Bowl round 15 cm / 6.0 inch	4	001.550500
Bowl round 18 cm / 7.0 inch	2	001.551029
Bowl round 21 cm / 8.3 inch	2	001.551689
Bowl round 23 cm / 9.0 inch	2	001.552348
Oval platter 28 cm / 11.0 x 8.0 inch	2	001.558553
Oval platter 31 cm / 12.2 x 9.1 inch	2	001.559213
Oval platter 35 cm / 13.8 x 10.2 inch	2	001.559872

¹ PU = Packing Unit
² Item-No refers to undecorated articles

VITALIS

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 28 cm / 11.0 inch	6	001.492009
Plate flat with rim 25,5 cm / 10.0 inch	6	001.491987
Plate flat with rim 23 cm / 9.1 inch	6	001.491355
Plate flat with rim 20 cm / 7.9 inch	6	001.491111
Soup plate with rim 25,5 cm / 10.0 inch	6	001.494089
Plate deep 23 cm / 9.1 inch	6	001.492341
Cup 1 0,18 ltr. / 6.0 oz.	6	001.494629
Saucer 1 15,5 cm / 6.1 inch	6	001.494587
Mug with handle 0,30 ltr. / 10.0 oz.	6	001.495105
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.495349
Mug with two handles 0,30 ltr. / 10.0 oz.	6	001.495525
Bowl round 16 cm / 6.3 inch	4	001.493230
Bowl round 16 cm / 6.3 inch	4	001.493561
Bowl round 12 cm / 4.7 inch	4	001.493825
Soup cup 0,35 ltr. / 11.6 oz.	6	001.492965
Saucer 17,5 cm / 6.9 inch	6	001.492663
Soup bowl with handle 0,50 ltr. / 16.7 oz. V203	6	001.496075
Compartment system platter 25,5 cm / 10.1 inch V219	2	001.496063



Spoons can easily be wiped off on the raised rims of flat and hollow items.

The famous »icing« on the cake...



Your cooking makes gourmets go into raptures.
The interior, decoration, accessoires, glasses ... **everything is of finest quality.**
There is only a small but essential detail missing

PORCELAIN WITH VIGNETTES



Your personal and distinctive logo on fine porcelain.
We can provide a quote – free of charge and obligation –
and a computer simulation for your customised porcelain.

Send us your templates and we'll do the rest!

SELTMANN WEIDEN – ... FROM SOLE PROPRIETORSHIP TO CORPORATE GROUP

The **Christian Seltsmann Porcelain Factory** (SELTSMANN-WEIDEN), founded in 1910, has evolved, through the takeover of the 'Royal Privileged Tettau Porcelain Factory' (KÖNIGLICH TETTAU) and the four specialist porcelain-manufacturers and art department absorbed in 1990 and 1995 to become a **group of companies** that is still today managed as a **family-run firm**. The group operates five factories employing around 1,000 people, producing exquisite porcelain for households, marketing – promotion – incentives, hotels and communal catering. It also creates stunning figurines and gifts.

As one of very few porcelain manufacturers to **operate worldwide**, the Seltsmann Group possesses an unusually wide range of production expertise: from **high-tech production** in one of Europe's most modern porcelain manufacturing plants to the **craftsmanship** of traditional artisans working by hand at the Rudolstadt workshops in Thuringia.

Consequently, the porcelain produced by the Seltsmann Group satisfies even the most exacting international demands in terms of design, function, resilience and exclusivity. It is precisely these product characteristics that can only be achieved at such **high standards** thanks to production in Germany. Reliability and flexibility are very important for the entrepre-



neurial Seltsmann family, as well as the development of particularly **environmentally sound production techniques**, which are immediately incorporated into the production facilities.



be green

At SELTSMANN WEIDEN, production in accordance with strict **environmental criteria** and **health guidelines** has always been a top priority.

To create a **credible, long-term** means of communicating this **eco-friendly approach** embraced by the whole Seltsmann Group, Seltsmann has developed an **environmental seal of quality** for its porcelain manufacturing activities.

MADE IN GERMANY

We produce in Germany

With its companies, the Seltsmann Group has more than **250 years of experience** in the manufacture of porcelain. The ever-expanding **production expertise** passed down through the generations cannot to this day be replaced.



Seltmann
Weiden

HOTEL



Porzellanfabriken Christian Seltmann GmbH
Postfach 2040 | 92610 Weiden/Germany
Tel: +49 (0) 961 / 204-0
Fax +49 (0) 961 / 204-119
E-Mail: hotel@seltmann.com

Homepage: hotel.seltmann.com



Ihr Fachhändler / *your dealer:*

MADE IN GERMANY

We produce in Germany